

Agilent 81689A, 81689B and 81649A Compact Tunable Laser Modules

User's Guide



#### Notices

This document contains proprietary information that is protected by copyright. All rights are reserved.

No part of this document may reproduced in (including electronic storage and retrieval or translation into a foreign language) without prior agreement and written consent from Agilent Technologies Deutschland GmbH as governed by United States and international copywright laws.

©Copyright 2001 by: Agilent Technologies Deutschland GmbH Herrenberger Str. 130 71034 Böblingen Germany

#### Subject Matter

The material in this document is subject to change without notice.

Agilent Technologies makes no warranty of any kind with regard to this printed material, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose.

Agilent Technologies shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance, or use of this material.

#### **Printing History**

New editions are complete revisions of the guide reflecting alterations in the functionality of the instrument. Updates are occasionally made to the guide between editions. The date on the title page changes when an updated guide is published. To find out the current revision of the guide, or to purchase an updated guide, contact your Agilent Technologies representative.

Control Serial Number: First Edition applies directly to all instruments.

#### Warranty

This Agilent Technologies instrument product is warranted against defects in material and workmanship for a period of one year from date of shipment. During the warranty period, Agilent will, at its option, either repair or replace products that prove to be defective.

For warranty service or repair, this product must be returned to a service facility designated by Agilent. Buyer shall prepay shipping charges to Agilent and Agilent shall pay shipping charges to return the product to Buyer. However, Buyer shall pay all shipping charges, duties, and taxes for products returned to Agilent from another country.

Agilent warrants that its software and firmware designated by Agilent for use with an instrument will execute its programming instructions when properly installed on that instrument. Agilent does not warrant that the operation of the instrument, software, or firmware will be uninterrupted or error free.

#### Limitation of Warranty

The foregoing warranty shall not apply to defects resulting from improper or inadequate maintenance by Buyer, Buyer-supplied software or interfacing, unauthorized modification or misuse, operation outside of the environmental specifications for the product, or improper site preparation or maintenance.

No other warranty is expressed or implied. Agilent Technologies specifically disclaims the implied warranties of Merchantability and Fitness for a Particular Purpose.

#### **Exclusive Remedies**

The remedies provided herein are Buyer's sole and exclusive remedies. Agilent Technologies shall not be liable for any direct, indirect, special, incidental, or consequential damages whether based on contract, tort, or any other legal theory.

#### Assistance

Product maintenance agreements and other customer assistance agreements are available for Agilent Technologies products. For any assistance contact your nearest Agilent Technologies Sales and Service Office.

#### Certification

Agilent Technologies Inc. certifies that this product met its published specifications at the time of shipment from the factory.

Agilent Technologies further certifies that its calibration measurements are traceable to the United States National Institute of Standards and Technology, NIST (formerly the United States National Bureau of Standards, NBS) to the extent allowed by the Institutes's calibration facility, and to the calibration facilities of other International Standards Organization members.

#### ISO 9001 Certification

Produced to ISO 9001 international quality system standard as part of our objective of continually increasing customer satisfaction through improved process control.

#### **Third Edition**

#### 81689-90A13

First Edition: 81689-90A11: September 2001

Second Edition: 81689-90A12: October 2001

Third Edition: 81689-90A13: February 2002

# **Safety Summary**

The following general safety precautions must be observed during all phases of operation, service, and repair of this instrument. Failure to comply with these precautions or with specific warnings elsewhere in this manual violates safety standards of design, manufacture, and intended use of the instrument. Agilent Technologies Inc. assumes no liability for the customer's failure to comply with these requirements.

**Before operation**, review the instrument and manual, including the red safety page, for safety markings and instructions. You must follow these to ensure safe operation and to maintain the instrument in safe condition.

The WARNING sign denotes a hazard. It calls attention to a procedure, practice or the like, which, if not correctly performed or adhered to, could result in injury or loss of life. Do not proceed beyond a WARNING sign until the indicated conditions are fully understood and met.

## **Safety Symbols**

The apparatus will be marked with this symbol when it is necessary for the user to refer to the instruction manual in order to protect the apparatus against damage.

Hazardous laser radiation.

## **Initial Inspection**

Inspect the shipping container for damage. If there is damage to the container or cushioning, keep them until you have checked the contents of the shipment for completeness and verified the instrument both mechanically and electrically.

The Performance Tests give procedures for checking the operation of the instrument. If the contents are incomplete, mechanical damage or defect is apparent, or if an instrument does not pass the operator's checks, notify the nearest Agilent Technologies Sales/Service Office.

To avoid hazardous electrical shock, do not perform electrical tests when there are signs of shipping damage to any portion of the outer enclosure (covers, panels, etc.).

#### WARNING





WARNING

#### WARNING

You *MUST* return instruments with malfunctioning laser modules to an Agilent Technologies Sales/Service Center for repair and calibration.

## **Line Power Requirements**

The Agilent 81689A, Agilent 81689B and Agilent 81649A Compact Tunable Laser Modules operate when installed in the Agilent 8163A and B Lightwave Multimeters, the Agilent 8164A and B Lightwave Measurement Systems, or the Agilent 8166A and B Lightwave Multichannel Systems.

Within this User's Guide, these instruments are collectively referred to as 'mainframes'.

## **Operating Environment**

The safety information in your mainframe's User's Guide summarizes the operating ranges for the Agilent 81689A, Agilent 81689B and Agilent 81649A Compact Tunable Laser Modules. In order for these modules to meet specifications, the operating environment must be within the limits specified for your mainframe.

## Input/Output Signals

There is one BNC input connector on the front panel of the Agilent 81689A, Agilent 81689B and Agilent 81649A Compact Tunable Laser Modules.

An absolute maximum of  $\pm$  6 V can be applied as an external voltage to any BNC connector.

## **Storage and Shipment**

Agilent 81689A Compact Tunable Laser modules can be stored or shipped at temperatures between  $-20^{\circ}$ C and  $+70^{\circ}$ C.

Agilent 81689B and Agilent 81649A modules can be stored or shipped at temperatures between  $-40^{\circ}$ C and  $+70^{\circ}$ C.

Protect the module from temperature extremes that may cause condensation within it.

#### CAUTION



## Initial Safety Information for Tunable Laser Modules

The laser sources specified by this user guide are classified according to IEC 60825-1 (2001)

The laser sources comply with 21 CFR 1040.10 except for deviations pursuant to Laser Notice No. 50, dated 2001-July-26

The Specifications for these modules are as follows:

	Agilent 81689A	Agilent 81689B	Agilent 81649A	
Laser Type	FP-Laser InGaAsP	FP-Laser InGaAsP	FP-Laser InGaAsP	
Wavelength range	1525-1575 nm	1525-1575 nm	1570-1620 nm	
Max. CW output power*	<15 mW	<35 mW	<35 mW	
Beam waist diameter	9 µm	9 μm	9 μm	
Numerical aperture	0.1	0.1	0.1	
Laser Class according to IEC 60825-1 (2001)- International	1M	1M	1M	
Max. permissible CW output power	163 mW	163 mW	163 mW	
* Max, CW output nower is defined as the highest possible ontical nower that the laser source can produce at its output connector				

#### Table 1 Tunable Laser Modules Laser Safety Information

\* *Max. CW output power* is defined as the highest possible optical power that the laser source can produce at its output connector. \*\* *Max. permissible CW output power* is the highest optical power that is permitted within the appropriate laser class.

## **Laser Safety Labels**

#### Laser class 1M label



#### Figure 1 Class 1M Safety Label - Agilent 81649A/89A/89B

A sheet of laser safety labels is included with the laser module as required. In order to meet the requirements of IEC 60825-1 we recommend that you stick the laser safety labels, in your language, onto a suitable location on the outside of the instrument where they are clearly visible to anyone using the instrument.

#### WARNING

Please pay attention to the following laser safety warnings:

- Under no circumstances look into the end of an optical cable attached to the optical output when the device is operational. The laser radiation can seriously damage your eyesight.
- Do not enable the laser when there is no fiber attached to the optical output connector.
- The laser is enabled by pressing the gray button close to the optical output connector on the front panel of the module. The laser is on when the green LED on the front panel of the instrument is lit.
- The use of optical instruments with this product will increase eye hazard.
- The laser module has a built-in safety circuitry which will disable the optical output in the case of a fault condition.
- Refer servicing only to qualified and authorised personnel.

# The Structure of this Manual

This manual is divided into two parts:

• Getting Started

This section gives an introduction to the Compact Tunable Laser modules. and aims to make these modules familiar to you:

- "Getting Started with Tunable Laser Sources" on page 17.
- Additional Information This is supporting information of a non-operational nature, concerning accessories, specifications, and performance tests:
  - "Accessories" on page 25,
  - "Specifications" on page 33, and
  - "Performance Tests" on page 45.

## **Conventions used in this manual**

- Hardkeys are indicated by italics, for example, Config, or Channel.
- Softkeys are indicated by normal text enclosed in square brackets, for example, [Zoom] or [Cancel].
- Parameters are indicated by italics enclosed by square brackets, for example, [*Range Mode*], or [*MinMax Mode*].
- Menu items are indicated by italics enclosed in brackets, for example, <*MinMax*>, or <*Continuous*>.

# **Table of Contents**

Safety Summary	3
Safety Symbols	3
Initial Inspection	3
Line Power Requirements	4
Operating Environment	4
Input/Output Signals	4
Storage and Shipment	4
Initial Safety Information for Tunable Laser Modules	3 5
Laser Safety Labels	6
The Structure of this Manual	8
Conventions used in this manual	8
Getting Started with Tunable Laser Sources	17
What is a Tunable Laser?	19
Installation	19
Agilent 81689A, 81689B, 81649A	
Compact Tunable Laser Module Front panels	19
Front Panel Controls and Indicators	20
Typical Use Models	21
Optical Output	22
Polarization Maintaining Fiber	22
Angled and Straight Contact Connectors	22
Signal Input and Output	23
Accessories	25
Modules and Options	27
Modules	28
User's Guides	28
Options	29
Option 021 - Compact Tunable Laser Modules	29
Option 022 - Compact Tunable Laser Modules	29
Option 071 - All Tunable Laser Modules	29
Option 072 - All Tunable Laser Modules	29
Connector Interfaces and Other Accessories	30

	Options 021, 071: Straight Contact Connectors	30
	Options 022, 072: Angled Contact Connectors	31
Specifications		33
	Definition of Terms	35
	Absolute Wavelength Accuracy	35
	Linewidth	35
	Minimum Output Power	35
	Modulation Extinction Ratio	36
	Modulation Frequency Range	36
	Output Power	36
	Output Isolation	36
	Peak Power	36
	Polarization Extinction Ratio	36
	Power Flatness Over Modulation	37
	Power Flatness Versus Wavelength	37
	Power Linearity	37
	Power Repeatability	37
	Power Stability	38
	Relative Intensity Noise (RIN)	38
	Relative Wavelength Accuracy	38
	Return Loss	39
	Sidemode Suppression Ratio	39
	Signal-to-Source Spontaneous Emission (SSE) Ratio	39
	Wavelength Range	39
	Wavelength Repeatability	40
	Wavelength Resolution	40
	Wavelength Stability	40
	Tunable Laser Module Specifications	41
	Supplementary Performance Characteristics	42
	Modulation	42
	General	43
	Environmental	43
Performance Test	S	45
	Required Test Equipment	47
	Test Record	47
	Test Failure	48

Instrument Specification	48
Performance Test Instructions	48
General Test Setup	49
Wavelength Tests	49
General Settings of Wavelength Meters for all Wavelength Tests	49
Wavelength Accuracy	49
Relative Wavelength Accuracy	49
Absolute Wavelength Accuracy	51
Wavelength Repeatability	51
Power Tests	52
Maximum Output Power	52
Power Linearity	54
Power Linearity - High Power Test	54
Example (Agilent 81689B)	55
Power Linearity	55
Power Flatness over Wavelength	56
Power Flatness over Wavelength	56
Power Stability	58
Optional Tests	59
Signal-to-Source Spontaneous Emission	59
Signal-to-Source Spontaneous Emission Tests	59
Test Record	63
Agilent 81689A Performance Test	65
Test Equipment Used	66
Relative Wavelength Accuracy	67
Wavelength Repeatability	68
Maximum Power Test	69
Power Linearity	69
Power Flatness	70
Power Stability	70
Optional lest	71
Signal-to-Source Spontaneous Emission (BW = 1 nm)	71
Agilent 81689B Performance Test	73
Test Equipment Used	74
Relative Wavelength Accuracy	/5
Wavelength Repeatability	/6 75
Maximum Power lest	// רר
Fower Elataose	// 70
Power Stability	70 78
Ontional Test	70
	73

Signal-to-Source Spontaneous Emission (BW = 1 nm)	79
Agilent 81649A Performance Test	81
Test Equipment Used	82
Relative Wavelength Accuracy	83
Wavelength Repeatability	84
Maximum Power Test	85
Power Linearity	86
Power Flatness Power Stability	8/ 97
Ontional Test	07 QQ
Signal-to-Source Spontaneous Emission (BW = 1 nm)	88
Cleaning Information	89
Safety Precautions	91
Why is it important to clean optical devices?	91
What do I need for proper cleaning?	92
Standard Cleaning Equipment	92
Dust and shutter caps	92
Isopropyl alcohol	93
Cotton swabs	93
Soft tissues	94
Pipe cleaner	94
Compressed air	94
Additional Cleaning Equipment	95
Microscope with a magnification range about 50X up to 300X	95
Ultrasonic bath Werm weter and liquid econ	95
Premoistened cleaning wines	90
Polymer film	96
Infrared Sensor Card	96
Preserving Connectors	97
Cleaning Instrument Housings	97
Which Cleaning Procedure should I use ?	98
How to clean connectors	98
How to clean connector adapters	99
How to clean connector interfaces	100
How to clean bare fiber adapters	101
How to clean lenses	102
How to clean instruments with a fixed connector inte	rface

#### 102

How to clean instruments with an optical glass plate 103 How to clean instruments with a physical contact interface 103

How to clean instruments with a recessed lens interface 104

How to clean optical devices which are sensitive to	
mechanical stress and pressure	105
How to clean metal filters or attenuator gratings	106
Additional Cleaning Information	107
How to clean bare fiber ends	107
How to clean large area lenses and mirrors	107
Other Cleaning Hints	109

# List of Figures

Figure 1	Class 1 Safety Label - Agilent 81650A/51A/52A/54A/11A/12A/13A/14A .	6
Figure 2	Class 1M Safety Label - Agilent 81655A/6A/7A, 81662A/3A/81480B/82B/	
81640B/42B/80B/82B/72B/49A/89A/	89B6	
Figure 3	Agilent 81689A Compact Tunable Laser Module	19
Figure 4	Agilent 81689B Compact Tunable Laser Module	20
Figure 5	Agilent 81649A Compact Tunable Laser Module	20
Figure 6	PMF Output Connector	22
Figure 7	Angled and Straight Contact Connector Symbols	23
Figure 8	Mainframes, Tunable Laser Modules, and Options	27
Figure 9	Options 021, 071: Single-mode fiber/PMF with Straight Contact Connectors .	30
Figure 10	Options 022, 072: Single-mode fiber/PMF with Angled Contact Connectors	31
Figure 11	Test Setup for Wavelength Tests	49
Figure 12	Test Setup for the Maximum Output Power Tests.	52
Figure 13	Test Setup for the Source Spontaneous Emission Test - High Power Outputs .	59
Figure 14	Signal-to-Spectral SSE Measurement	61

# Getting Started with Tunable Laser Sources

This chapter describes the Agilent 81689A, Agilent 81689B and Agilent 81649A Compact Tunable Laser modules.

# What is a Tunable Laser?

A Tunable Laser is a laser source for which the wavelength can be varied through a specified range. The Agilent Technologies range of tunable laser modules also allow you to set the output power, and to choose between continuous wave or modulated power.

The Agilent Technologies range of compact tunable laser modules are flexible stimulus modules suitable for applications such as the test of optical amplifiers, DWDM components, and complete DWDM systems.

## Installation

The Agilent 81689A, Agilent 81689B, and Agilent 81649A are frontloadable modules. For a description of how to install your module, refer to "How to Fit and Remove Modules" in the Installation and Maintenance chapter of your mainframe's User's Guide.

## Agilent 81689A, 81689B, 81649A Compact Tunable Laser Module Front panels



Figure 3 Agilent 81689A Compact Tunable Laser Module



Figure 4 Agilent 81689B Compact Tunable Laser Module



Figure 5 Agilent 81649A Compact Tunable Laser Module

#### **Front Panel Controls and Indicators**

Switch the laser source on or off using the switch on its front panel, using the [*State*] parameter in the instrument's Graphical User Interface, or remotely using GP-IB commands. When the Active LED is lit the source is emitting radiation. When the Active LED is not lit the source is not emitting radiation.

## **Typical Use Models**

Brief description	The Agilent 81689A Compact Tunable Laser module operates in the C-band between 1525 nm and 1575 nm.
	The Agilent 81689B Compact Tunable Laser module also operates in the C-band between 1525 nm and 1575 nm. When compared with the Agilent 8169A, the Agilent 8169B offers increased output power, and higher relative wavelength accuracy and wavelength stability.
	The Agilent 81649A Compact Tunable Laser module operates in the L-band between 1570 nm and 1620 nm
Test systems for optical amplifiers	You can use a selection of fully remote-controlled Agilent Compact Tunable Laser modules, in combination with an Agilent 81682A or Agilent 81642A high power Tunable Laser module, to provide the high stimulus power needed to characterize optical amplifiers intended for DWDM applications. When used with an Agilent 81651A Optical Attenuator module a dynamic range of more than 60 dB can be achieved. Without the attenuator module, the Agilent 81689A and Agilent 81649A Compact Tunable Laser modules' output power can be attenuated by 9 dB, and the Agilent 81689B Compact Tunable Laser module's output power can be attenuated by 10 dB, allowing you to equalize the power delivered from several sources.
Test systems for integrated optical devices	You can use Agilent Compact Tunable Laser modules that include a Panda Polarizing Maintaining Fiber (PMF) output port (optional) as the well-defined polarization sources required to test devices such as waveguides.
Test systems for DWDM multichannel transmission systems	You can use Agilent Compact Tunable Laser modules to set up a realistic multichannel test-bed for DWDM transmission systems in the C-Band or L-Band. Their continuous, mode-hop free tuning makes it quick and easy for you to set up even the most complex configurations to the target wavelengths and power levels required during installation and maintenance.
Compact spare for DFB modules in ITU grids	The Agilent 81689B Compact Tunable Laser module can replace, without power penatlty, any of a comb of Agilent 81662A DFB Laser Source modules emitting between 1525 nm and 1575 nm.
Smart loss testers with selectable wavelength	You can use an Agilent 8163A or B Lightwave Multimeter, an Agilent Power Sensor module, and an Agilent Compact Tunable Laser module as a smart loss-test set with selectable wavelength.

# **Optical Output**

## **Polarization Maintaining Fiber**

A Polarization maintaining fiber (PMF) output is available as an option for Agilent 81689A, Agilent 81689B and Agilent 81649A Compact Tunable Laser modules.

PMF is aligned to maintain the state of polarization. A well defined state of polarization helps ensure constant measurement conditions.

The fiber is of Panda type, with TE mode in the slow axis in line with the connector key..



#### Figure 6 PMF Output Connector

See *"Accessories" on page 25* for further details on connector interfaces and accessories.

#### **Angled and Straight Contact Connectors**

Angled contact connectors are available as an option for Agilent 81689A, Agilent 81689B and Agilent 81649A Compact Tunable Laser modules.

Angled contact connectors help you to control return loss, since reflected light tends to reflect into the cladding, reducing the amount of light that reflects back to the source. 

 CAUTION
 If the contact connector on your instrument is angled, you can only use cables with angled connectors with the instrument.

 Angled Contact
 Straight Contact

 Connector Symbol
 Straight Contact

 Connector Symbol
 Straight Contact

 Figure 7
 Angled and Straight Contact Connector Symbols

 Figure 7 shows the symbols that tell you whether the contact connector of your Tunable Laser module is angled or straight. The angled contact connector symbol is colored green.

 You should connect straight contact fiber end connectors with neutral sleeves to straight contact connectors and connect angled contact fiber end connectors.

**NOTE** You cannot connect angled non-contact fiber end connectors with orange sleeves directly to the instrument.

See "Accessories" on page 25 for further details on connector interfaces and accessories.

# **Signal Input and Output**

#### CAUTION



There is one BNC input connector on the front panel of the Agilent 81689A, Agilent 81689B and Agilent 81649A Compact Tunable Laser modules

An absolute maximum of  $\pm$  6 V can be applied as an external voltage to any BNC connector.

Accessories

The Agilent 81689A, Agilent 81689B and Agilent 81649A Compact Tunable Laser modules are available in various configurations for the best possible match to the most common applications.

This chapter provides information on the available options and accessories.

# **Modules and Options**

Figure 8 shows all the options that are available for Agilent 81689A, Agilent 81689B and Agilent 81649A Compact Tunable Laser modules, and the instruments that support these modules.



Figure 8 Mainframes, Tunable Laser Modules, and Options

# Modules

Agilent 81689A, Agilent 81689B and Agilent 81649A Compact Tunable Laser modules can be hosted by:

- Agilent 8163A and Agilent 8163B Lightwave Multimeters,
- Agilent 8164A and Agilent 8164B Lightwave Measurement Systems,
- Agilent 8166A and Agilent 8166B Lightwave Multichannel Systems.

Compact Tunable Laser Modules			
Model No.	Description		
Agilent 81689A	Compact Tunable Laser for Multi-Channel Test Applications, C-Band, + 6 dBm		
Agilent 81689B	Compact Tunable Laser for Multi-Channel Test Applications, C-band, + 10 dBm		
Agilent 81649A	Compact Tunable Laser for Multi-Channel Test Applications, L-Band, + 6 dBm		

## **User's Guides**

User's Guides				
Opt	Description	Part No.		
8169A 0BF	Agilent 81689A, Agilent 81689B and Agilent 81649A Compact Tun- able Laser modules User's Guide	81689-90A11		
OBF	Agilent 81480A, Agilent 81680A, Agilent 81640A, Agilent 81682A & Agilent 81642A Tunable Laser Modules	81680-90A17		
8164B 0BF	Agilent 8163A/B Lightwave Multimeter, Agilent 8164A/B Light- wave Measurement System, & Agilent 8166A/B Lightwave Multi- channel System User's Guide	08164-90B12		
8164B 0B2	Agilent 8163A/B Lightwave Multimeter, Agilent 8164A/B Light- wave Measurement System, & Agilent 8166A/B Lightwave Multi- channel System Programming Guide	08164-90B62		

## **Options**

#### **Option 021 - Compact Tunable Laser Modules**

Standard single-mode fiber, for straight contact connectors.

#### **Option 022 - Compact Tunable Laser Modules**

Standard single-mode fiber, for angled contact connectors.

#### **Option 071 - All Tunable Laser Modules**

Polarization-maintaining fiber, Panda-type, for straight contact connectors.

#### **Option 072 - All Tunable Laser Modules**

Polarization-maintaining fiber, Panda-type, for angled contact connectors.

# **Connector Interfaces and Other Accessories**

## **Options 021, 071: Straight Contact Connectors**

If you want to use straight connectors (such as FC/PC, Diamond HMS-10, DIN, Biconic, SC, ST or D4) to connect to the instrument, you must do the following:

**1** Attach your connector interface to the interface adapter.

See Table 2 for a list of the available connector interfaces.

**2** Connect your cable (see Figure 9).

Ag C I I H	gilent 810 00AI connector Interface Diamond HMS-10	Agilent 810 00FI Connector Interface FC/PC/SPC	Agilent 810 00GI Connector Interface D4	Agilent 810 00HI Connector Interface Diamond E-2000	Agilent 810 00KI Connector Interface SC/PC/SPC	Agilent 810 00SI Connector Interface DIN 47256	Agilent 810 00VI Connector Interface ST	Agilent 8100 0WI Connector Interface Biconic

Figure 9 Options 021, 071: Single-mode fiber/PMF with Straight Contact Connectors

Table 2 Straight Contact Connector Interfaces

Description	Model No.
Biconic	Agilent 81000 WI
D4	Agilent 81000 GI
Diamond HMS-10	Agilent 81000 Al
DIN 47256	Agilent 81000 SI
FC / PC / SPC	Agilent 81000 FI
SC/PC/SPC	Agilent 81000 KI
ST	Agilent 81000 VI
Diamond E-2000	Agilent 81000 HI

# **Options 022, 072: Angled Contact Connectors**

If you want to use angled connectors (such as FC/APC, Diamond HRL-10, or SC/APC) to connect to the instrument, you must do the following:

**1** Attach your connector interface to the interface adapter.

See Table 3 for a list of the available connector interfaces.

**2** Connect your cable (see Figure 10).





 Table 3
 Angled Contact Connector Interfaces

Description	Model No.
DIN 47256-4108.6	Agilent 81000 SI
FC / APC	Agilent 81000 NI
SC / APC	Agilent 81000 KI
Diamond E-2000	Agilent 81000 HI

Specifications

The Agilent 81689A, Agilent 81689B and Agilent 81649A Compact Tunable Laser modules are produced to the ISO 9001 international quality system standard as part of Agilent Technologies' commitment to continually increasing customer satisfaction through improved quality control.

Specifications describe the modules' warranted performance. Supplementary performance characteristics describe the modules non-warranted typical performance.

Because of the modular nature of the instrument, these performance specifications apply to these modules rather than the mainframe unit.

# **Definition of Terms**

This section defines terms that are used both in this chapter and *"Performance Tests" on page 45.* 

Generally, all specifications apply for the given environmental conditions and after warmup time.

Measurement principles are indicated. Alternative measurement principles of equal value are also acceptable.

### **Absolute Wavelength Accuracy**

The maximum difference between the actual wavelength and the displayed wavelength of the TLS. Wavelength is defined as wavelength in vacuum.

*Conditions*: constant power level, temperature within operating temperature range, coherence control off, measured at high power output.

*Measurement* with wavelength meter. Averaging time given by wavelength meter,  $\geq 1$  s.

## Linewidth

The 3-dB width of the optical spectrum, expressed in Hertz.

*Conditions*: temperature within operating temperature range, coherence control off, power set to maximum flat power (maximum attainable power within given wavelength range).

*Measurement* with self-heterodyning technique: the output of the laser under test is sent through a Mach-Zehnder interferometer in which the length difference of the two arms is longer than the coherence length of the laser. The electrical noise spectrum of the photodetector current is measured with an Agilent Lightwave Signal Analyzer, and the linewidth is calculated from the heterodyne spectrum (Lightwave signal analyzer settings: resolution bandwidth 1 MHz; video bandwidth 10 kHz; sweep time 20 ms; single scan).

## **Minimum Output Power**

The minimum output power for which the specifications apply.

## **Modulation Extinction Ratio**

The ratio of total power in on-state to total power in off-state, expressed in dB.

*Conditions*: Internal or external modulation, tunable laser at highest power setting.

*Measurement* with optical spectrum analyzer. Tunable laser switched on and off.

### **Modulation Frequency Range**

The range of frequencies for which the modulation index is above -3 dB of the highest modulation index. In this context, modulation index is defined as the AC power amplitude (peak-to-peak) divided by the average power.

#### **Output Power**

The achievable output power for the specified TLS tuning range.

Conditions: temperature within operating temperature range.

*Measurement* with power meter at the end of a single-mode fiber patchcord.

## **Output Isolation**

The insertion loss of the built-in isolator in the backward direction.

*Measurement*: Cannot be measured from the outside. This characteristic is based on known isolator characteristics.

## **Peak Power**

The highest optical power within specified wavelength range.

## **Polarization Extinction Ratio**

The ratio of optical power in the slow axis of the polarizationmaintaining fiber to optical power in the fast axis within a specified wavelength range.

*Conditions*: only applicable for TLS with polarization maintaining fiber with the TE mode in slow axis and oriented in line with connector key, at constant power level.
Measurement with a polarization analyzer at the end of a polarizationmaintaining patchcord, by sweeping the wavelength, thereby creating circular traces on the Poincaré sphere, then calculating the polarization extinction ratio from the circle diameters.

#### **Power Flatness Over Modulation**

When changing the wavelength and modulation frequency, and measuring the differences between actual and displayed power levels (in dB), the power flatness is  $\pm$  half the span between the maximum and the minimum value of all differences.

*Conditions:* uninterrupted line voltage, constant power setting, temperature within ±2 K, external modulation ON.

Measurement with optical power meter.

#### **Power Flatness Versus Wavelength**

When changing the wavelength at constant power setting and recording the differences between actual and displayed power levels, the power flatness is  $\pm$  half the span (in dB) between the maximum and the minimum of the measured power levels.

Conditions: uninterrupted TLS output power, constant power setting, temperature within  $\pm 1$ K.

*Measurement* with optical power meter.

#### **Power Linearity**

When changing the power level and measuring the differences (in dB) between actual and displayed power levels, the power linearity is  $\pm$  half the span (in dB) between the maximum and the minimum value of all differences.

*Conditions*: power levels from within specified output power range, uninterrupted TLS output power, at fixed wavelength settings and stable temperature.

Measurement with optical power meter.

### **Power Repeatability**

The random uncertainty in reproducing the power level after changing and re-setting the power level. The power repeatability is  $\pm$  half the span (in dB) between the highest and lowest actual power. *Conditions*: uninterrupted TLS output power, constant wavelength, temperature within  $\pm 1$  K, short time span.

Measurement with optical power meter.

**NOTE** The long-term power repeatability can be obtained by taken the power repeatability and power stability into account.

#### **Power Stability**

The change of the power level during given time span, expressed as  $\pm$  half the span (in dB) between the highest and lowest actual power.

*Conditions*: uninterrupted TLS output power, constant wavelength and power level settings, temperature within  $\pm 1$  K, time span as specified.

Measurement with optical power meter.

#### **Relative Intensity Noise (RIN)**

The square of the (spectrally resolved) RMS optical power amplitude divided by the measurement bandwidth and the square of the average optical power, expressed in dB/Hz.

*Conditions*: at specified output power, coherence control off, temperature within operating temperature range, frequency range 0.1 to 6 GHz.

Measurement with Agilent Lightwave Signal Analyzer.

#### **Relative Wavelength Accuracy**

When randomly changing the wavelength and measuring the differences between the actual and displayed wavelengths, the relative wavelength accuracy is  $\pm$  half the span between the maximum and the minimum value of all differences.

*Conditions*: uninterrupted TLS output power, constant power level, temperature within operating temperature range, observation time 10 minutes maximum (constant temperature), coherence control off, measured at high power output.

*Measurement* with wavelength meter. Averaging time given by wavelength meter,  $\geq 1$  s.

#### **Return Loss**

The ratio of optical power incident to the TLS output port, at the TLS's own wavelength, to the power reflected from the TLS output port.

Conditions: TLS disabled.

#### Sidemode Suppression Ratio

The ratio of average signal power to the optical power of the highest sidemode within a distance from 0.1 to 6 GHz to the signal's optical frequency, expressed in dB.

*Conditions*: at a specified output power and wavelength range, temperature within operating temperature range, coherence control off.

*Measurement* with the Agilent Lightwave Signal Analyzer, by analyzing the heterodyning between the main signal and the highest sidemode.

# Signal-to-Source Spontaneous Emission (SSE) Ratio

The ratio of signal power to maximum spontaneous emission power in 1 nanometer bandwidth within a  $\pm 3$  nm window around the signal wavelength, where  $\pm 1$  nm around the signal wavelength are excluded, at the specified output power, expressed in dB/nm.

*Conditions*: output power set to specified values, at temperatures within operating temperature range, coherence control off.

*Measurement* with optical spectrum analyzer (OSA) at 0.5 nm resolution bandwidth (to address the possibility of higher SSE within a narrower bandwidth), then extrapolated to 1 nm bandwidth. On low-SSE output (if applicable), with fiber Bragg grating inserted between the TLS and the OSA in order to suppress the signal, thereby enhancing the dynamic range of the OSA.

**NOTE** The specified signal-to-SSE ratio is also applicable to output powers higher than the specified values.

#### Wavelength Range

The range of wavelengths for which the specifications apply.

### Wavelength Repeatability

The random uncertainty in reproducing a wavelength after detuning and re-setting the wavelength. The wavelength repeatability is  $\pm$  half the span between the maximum and the minimum value of all actual values of this wavelengths.

*Conditions*: uninterrupted TLS output power, constant power level, temperature within operating temperature range, coherence control off, short time span.

*Measurement* with wavelength meter at high power output. Averaging time given by wavelength meter,  $\geq 1$  s.

**NOTE** The long-term wavelength repeatability can be obtained by taken the wavelength repeatability and wavelength stability into account.

#### Wavelength Resolution

The smallest possible displayed wavelength increment/decrement.

### Wavelength Stability

The change of wavelength during given time span, expressed as  $\pm$  half the span between the maximum and the minimum of all actual wavelengths.

Conditions: uninterrupted TLS output power, constant wavelength and power level settings, coherence control off, temperature within  $\pm 1$  K, time span as specified.

*Measurement* with wavelength meter. Averaging time given by wavelength meter,  $\geq 1$  s.

## **Tunable Laser Module Specifications**

	Agilent 81689A	Agilent 81689B	Agilent 81649A
Wavelength range	1525 nm to 1575 nm	1525 nm to 1575 nm	1570 nm to 1620 nm
Wavelength resolution	0.01 nm, 1.25 GHz at 1550 nm	0.01 nm, 1.25 GHz at 1550 nm	0.01 nm, 1.17 GHz at 1595 nm
Absolute wavelength accuracy (typ.) <sup>1</sup>	$\pm$ 0.3 nm	± 0.3 nm	± 0.3 nm
Relative wavelength accuracy <sup>1</sup>	$\pm$ 0.3 nm	± 0.15 nm	± 0.15 nm
Wavelength repeatability <sup>1</sup>	± 0.05 nm	± 0.05 nm	± 0.05 nm
Wavelength stability <sup>1</sup>			
typ, over 24 h at constant temperature:	$\pm$ 0.02 nm	± 0.01 nm	±0.01 nm
typ, over 1 h at constant temperature:		$\pm$ 0.005 nm	$\pm$ 0.005 nm
Tuning speed (typ.)	< 10 sec / 50 nm	< 10 sec / 50 nm	< 10 sec / 50 nm
Linewidth (typ.) <sup>2</sup>	20 MHz	< 20 MHz	< 20 MHz
with Coherence Control ON (typ.) <sup>2</sup>		> 100 MHz	> 100 MHz
Output power (continuous power on during tuning)	≥ 6 dBm (1525 - 1575 nm)	≥ 10 dBm (1525 - 1575 nm)	≥ 6 dBm (1570 - 1620 nm)
Minimum output power	— 3 dBm	0 dBm	— 3 dBm
Power stability	± 0.03 dB over1 hour	± 0.015 dB over 1 hour,	$\pm$ 0.015 dB over 1 hour,
(at constant temperature) <sup>3</sup>		typ. $\pm$ 0.0075 dB over 1 hour,	typ. ± 0.0075 dB over 1 hour,
	typ. $\pm0.06$ dB over 24 hours	typ. $\pm$ 0.05 dB over 24 hours	typ. $\pm$ 0.05 dB over 24 hours
Power repeatability (typ.) <sup>3</sup>	$\pm$ 0.02 dB	$\pm$ 0.02 dB	$\pm$ 0.02 dB
Power linearity	$\pm$ 0.1 dB	$\pm$ 0.1 dB	$\pm$ 0.1 dB
Power flatness versus wavelength	$\pm$ 0.3 dB	$\pm$ 0.2 dB	$\pm$ 0.2 dB
Side-mode Suppression ratio (typ.) <sup>2</sup>	> 40 dBc (1525 - 1575 nm at 0 dBm)	> 45 dBc (1525 - 1575 nm at ≥ 3 dBm)	> 45 dBc (1570 - 1620 nm at ≥ 0 dBm)
Signal-to-Source Spontaneous Emission Ratio (typ.) <sup>4</sup>	≥ 39 dB/nm (1525 - 1575 nm at 6 dBm)	≥ 44 dB/nm (1525 - 1575 nm at 10 dBm)	≥ 42 dB/nm (1570 - 1620 nm at 6 dBm)

	Agilent 81689A	Agilent 81689B	Agilent 81649A
Relative Intensity noise (RIN, typ.)	<	< -137 dB/Hz (100 MHz - 2.5 GHz) at + 7 dBm	< -137 dB/Hz (100 MHz - 2.5 GHz) at + 3 dBm
Dimensions	75 mm H, 32 mm W, 335 mm D (2.8" × 1.3" × 13.2")	75 mm H, 32 mm W, 335 mm D (2.8" × 1.3" × 13.2")	75 mm H, 32 mm W, 335 mm D (2.8" × 1.3" × 13.2")
Weight	1 kg	1 kg	1 kg
1. At CW operation. Measured with wavele	angth meter based on wavelength	in vacuum.	
2. Measured by heterodyning method.			

3.500 ms after changing power.

4. Measured with optical spectrum analyzer at 1 nm resolution bandwidth.

## **Supplementary Performance Characteristics**

## Modulation

Internal Digital Modulation	50% duty cycle, 200 Hz to 300 kHz > 45% duty cycle, 300 Hz to 1 MHz
	Modulation output (via Mainframe): TTL reference signal.
External Digital Modulation	> 45% duty cycle, fall time < 300 ns, 200 Hz to 1 MHz
	Modulation Input (via Mainframe): TTL signal.
External Analog Modulation	$\ge 15\%$ modulation depth, 5 kHz to 1 MHz
	Modulation input: 5 Vp-p
Coherence Control (Agilent 81649A and 81689B)	For measurements on components with 2 m long patchcords and connectors with 14 dB return loss, the effective linewidth results in a typical power stability of $< \pm 0.025$ dB over 1 minute by reducing interference effects in the test setup.

## General

Output Isolation (typ.)	38 dB
Return loss (typ.)	55 dB (options 022, 072); 40 dB (options 021, 071).
Polarization Maintaining Fiber (Options 071, 072):	<b>Fiber type:</b> Panda. <b>Orientation:</b> TE mode in slow axis, in line with connector key. <b>Extinction Ratio:</b> 16 dB typ.
Recommended Recalibration Period:	2 years.
Warm-up Time:	< 40 min, immediate operation after boot-up.
	Environmental
Storage Temperature:	-20°C to +70°C (81689A)
	-40°C to +70°C (81689B, 81649A)

< 80% R.H. at 15°C to 35°C

Specifications are valid in non-condensing conditions.

**Operating Temperature:** 15°C to 35°C

Humidity:

**Performance Tests** 

Agilent 81689A, 81689B and 81649A Tunable Laser Modules User's Guide, Third Edition

The procedures in this section tests the optical performance of the instrument. The complete specifications to which the Agilent 81689A, Agilent 81689B and Agilent 81649A Compact Tunable Laser modules are tested are given in *"Specifications" on page 33*. All tests can be performed without access to the interior of the instrument. The performance tests refer specifically to tests using the Diamond HMS-10/Agilent connector.

## **Required Test Equipment**

The equipment required for the Performance Test is listed in Table 4. Any equipment that satisfies the critical specifications of the equipment given in Table 4 may be substituted for the recommended models.

Instrument	Description of Instrument/Accessory	#021, #071	#022, #072
Agilent 86142B <sup>1</sup>	Optical Spectrum Analyzer	1	1
Agilent 8164A/B <sup>2</sup>	Lightwave Measurement System	1	1
WA-1500 <sup>3</sup>	Burleigh Wavemeter	1	1
81618A or 81619A <sup>4</sup>	Optical Head Interface Module	1	1
81626B <sup>4</sup>	Standard Optical Head	1	1
Agilent 81000SA	DIN 47256/4108 Connector Adapter	1	1
Agilent 81000AI	HMS-10 Connector Interface	1	
Agilent 81000SI	DIN 47256/4108 Connector Interface		1
Agilent 81000Fl	FC/PC Connector Interface	1	
Agilent 81101PC	Diamond HMS-10/Agilent FC/PC Patchcord	1	
Agilent 81113PC	Diamond HMS-10/Agilent FC/Super PC Patchcord	1	1
Agilent 81113SC	Diamond HMS-10/Agilent DIN 47256/4108 Patchcord		1
<sup>1</sup> You can use the HP 71452B or HP 71450A #100 instead of the Agilent 86142B.			
<sup>2</sup> You can use the 8163A/B or 8166A/B instead of the 8164A/B			
<sup>3</sup> You can use the 86120C instead of the WA-1500			
<sup>4</sup> For the 81689A and 81649A you can use the 81624B or 81627B, instead of the 81626B. For the 81689A, 81689B and 81649A you can use the 81525A + 81533B instead of the 81626B + 81618A			3.

Table 4	Equipment Requi	ired
---------	-----------------	------

### **Test Record**

Results of the performance test may be tabulated in the Test Record provided at the end of the test procedures. It is recommended that you fill out the Test Record and refer to it while doing the test. Since the test limits and setup information are printed on the Test Record for easy reference, the record can also be used as an abbreviated test procedure (if you are already familiar with the test procedures). The Test Record can also be used as a permanent record and may be reproduced without written permission from Agilent Technologies.

### **Test Failure**

Always ensure that you use the correct cables and adapters, and that all connectors are undamaged and extremely clean.

If the Agilent 81689A, Agilent 81689B or Agilent 81649A Compact Tunable Laser Modules fails any performance test, return the instrument to the nearest Agilent Technologies Sales/Service Office for repair.

### **Instrument Specification**

Specifications are the performance characteristics of the instrument which are certified. These specifications, listed in *"Specifications" on page 33*, are the performance standards or limits against which the Agilent 81689A, Agilent 81689B and Agilent 81649A Compact Tunable Laser modules can be tested.

The specifications also list some supplemental characteristics of the Agilent 81689A, Agilent 81689B and Agilent 81649A Compact Tunable Laser modules. Supplemental characteristics should be considered as additional information.

Any changes in the specifications due to manufacturing changes, design, or traceability to the National Institute of Standards and Technology (NIST), will be covered in a manual change supplement, or revised manual. Such specifications supersede any that were previously published.

## **Performance Test Instructions**

- **NOTE** Make sure that all fiber connectors are clean.
  - Turn the instruments on, enable the laser and allow the instruments to warm up.
  - Ensure that the Device Under Test (DUT) and all the test equipment is held within the environmental specifications given in *"Specifications" on page 33*

#### **General Test Setup**

Insert an Agilent 81689A, Agilent 81689B or Agilent 81649A Compact Tunable Laser Module from the front into slot 1 of the Agilent 8164A/B Lightwave Measurement System.

#### **Wavelength Tests**

Connect the Tunable Laser module to the Wavelength Meter as shown in Figure 11.



Figure 11 Test Setup for Wavelength Tests

## General Settings of Wavelength Meters for all Wavelength Tests

Set the Burleigh WA-1500 to the following settings:

- Set Display to Wavelength.
- Set Medium to Vacuum.
- Set Resolution to Auto.
- Set Averaging to On.
- Set Input Attenuator to Auto.

#### Wavelength Accuracy

The steps below explain how to calculate the Relative Wavelength Accuracy, and the Absolute Wavelength Accuracy Result.

#### **Relative Wavelength Accuracy**

1 Move to the Tunable Laser channel of the Agilent 8164A/B Lightwave Measurement System and press [Menu]. **2** Set the menu parameters to the values shown in Table 5.

#### Table 5 Tunable Laser Channel Settings

Tunable Laser Channel Menu Parameters	Values
<wavelength mode=""></wavelength>	<λ>
<source state=""/>	<0ff>
<power unit=""></power>	<dbm></dbm>
<power mode=""></power>	<automatic></automatic>

**3** Set the wavelength and power of your Tunable Laser module to the values given in Table 6.

#### Table 6 Initial Wavelength and Power Settings for Relative Wavelength Accuracy Tests

Module	Wavelength $[\lambda]$	Power [P]
Agilent 81689A	1525.000 nm	– 3.00 dBm
Agilent 81689B	1525.000 nm	0.00 dBm
Agilent 81649A	1570.000 nm	– 3.00 dBm

- **4** Press the key beside the laser output to switch on the laser output.
- 5 Wait until the wavelength meter has settled, then note the wavelength displayed on the wavelength meter in the test record.
- **6** Increase the wavelength setting of the Tunable Laser module by the steps shown in the test record.
- **7** Repeat steps 5 and 6 up to the maximum wavelength values shown in Table 7.

#### Table 7 Maximum Wavelength for Relative Wavelength Accuracy Tests

Tunable Laser Module	Maximum Wavelength Value
Agilent 81689A	1575 nm
Agilent 81689B	1575 nm
Agilent 81649A	1620 nm

- 8 Repeat steps 3 through 7 another 4 times.
- **9** From each repetition of the measurements, pick the maximum and minimum deviations, and note these values in the test record.

## 10 Determine the Relative Wavelength Accuracy, Summary of all Repetitions:

- **a** Pick the largest Maximum Deviation, and note it as the Largest Maximum Deviation in the test record.
- **b** Pick the smallest Minimum Deviation, and note it as the Smallest Minimum Deviation in the test record.

**NOTE** The largest Maximum Deviation is the largest positive value and the smallest Minimum Deviation is the largest negative value (largest deviation above and below zero respectively).

#### 11 Determine the Relative Wavelength Accuracy Result:

Subtract the Smallest Minimum Deviation from the Largest Maximum Deviation. Record this value as the **Relative Wavelength Accuracy Result**.

#### **Absolute Wavelength Accuracy**

12 From the measurements taken in the Relative Wavelength Accuracy test, pick the largest absolute value from either the Largest Maximum Deviation or the Smallest Minimum Deviation taken in step 11, and note this value as Absolute Wavelength Accuracy.

### Wavelength Repeatability

- 1 Move to the Tunable Laser channel of the Agilent 8164A/B Lightwave Measurement System and press [Menu].
- **2** Set the menu parameters to the values shown in Table 5.
- **3** Set the wavelength and power for each Tunable Laser module to the values given in Table 8.

#### Table 8 Reference Wavelength and Power Settings for Wavelength Repeatability Tests

Module	Wavelength $[\lambda]$	Power [P]
Agilent 81689A	1525.000 nm	— 3.00 dBm
Agilent 81689B	1525.000 nm	0.00 dBm
Agilent 81649A	1570.000 nm	— 3.00 dBm

- **4** Press the key beside the laser output to switch on the laser.
- **5** Wait until the wavelength meter has settled. Then measure the wavelength with the wavelength meter and note the result in test record as Initial Setting, the reference wavelength, "REF".
- 6 Set the wavelength of your Tunable Laser module to any wavelength in its range (in the test record, this is given in column "from {wavelength} to REF").
- **7** Set the wavelength of your Tunable Laser module back to the Reference Wavelength and wait until the wavelength meter has settled.

- 8 Measure the wavelength with the Wavelength Meter and note the result in test record.
- **9** Repeat steps 6 through 8 with all wavelength settings given by "from {wavelength} to REF" in the test record.
- **10** From all wavelength measurements pick the largest measured value and the smallest measured value.
- **11** Calculate the wavelength repeatability by subtracting the largest measured value from the smallest measured value.

### **Power Tests**

#### **Maximum Output Power**

Make sure the instruments have warmed up before starting the measurement.

- **NOTE** Absolute Power Accuracy is not specified.
  - The result of the measurement below is greatly influenced by the quality and the matching of the interconnections used.
  - **1** Set up the equipment as shown in Figure 12.



#### Figure 12 Test Setup for the Maximum Output Power Tests

- **2** Set the Power Meter to the following settings:
  - a Select Automatic ranging. This is the default setting.
  - **b** Set the Averaging Time to 500 ms.
  - **c** Select *dBm* as the power units.
  - **d** While the laser is switched off, Zero the power meter. From [Menu] press [Zero].

- **3** Move to the Tunable Laser channel of the Agilent 8164A/B Lightwave Measurement System and press [Menu].
- **4** Set the menu parameters to the values shown in Table 5.
- **5** Set the wavelength and power for each Tunable Laser module to the values given in Table 9.

#### Table 9 Reference Wavelength and Power Values for Maximum Output Power Tests

Module	Wavelength $[\lambda]$	Power [P]
Agilent 81689A	1525.000 nm	+13.00 dBm
Agilent 81689B	1525.000 nm	+13.00 dBm
Agilent 81649A	1570.000 nm	+13.00 dBm

- **NOTE** The laser output is limited to its maximum possible value at this wavelength, the display will probably show ExP.
  - **6** Press the key beside the laser output to switch on the laser.
  - 7 Set the wavelength of the 81626B to the same as your Tunable Laser module, as given in Table 9.
  - 8 Measure the output power with the 81626B and note the result for this wavelength in the test record.
  - 9 Increase  $\lambda$ , the output wavelength, of the Tunable Laser module to the next value given in the test record.
  - **10** Increase the wavelength of the 81626B to the same value.
  - **11** Note the measured power in the test record for each wavelength
  - 12 Repeat item 9 to item 11 for the full wavelength range

### **Power Linearity**

#### **Power Linearity - High Power Test**

- **1** Set up the equipment as shown in Figure 12.
- **2** Move to the Tunable Laser channel of the Agilent 8164A/B Lightwave Measurement System and press [Menu].
- **3** Set the menu parameters to the values shown in Table 5.
- **4** Set the wavelength and power for each Tunable Laser module to the values given in Table 10

## Table 10 Wavelength and Power Settings for High Power Linearity Tests without Attenuation Attenuation

Module	Wavelength $[\lambda]$	Power [P]
Agilent 81689A	1540.000 nm	+6.000 dBm
Agilent 81689B	1540.000 nm	+10.000 dBm
Agilent 81649A	1600.000 nm	+6.000 dBm

- **5** Make sure the optical output is switched off.
- **6** Set the 81626B to the following settings:
  - a Zero the 81626B; from [Menu] press [Zero].
  - **b** Select Automatic ranging. This is the default setting.
  - c Set the Averaging Time to 500 ms.
  - **d** Select dB as the power units.
  - e Set  $\lambda$ , the wavelength, to the same as your Tunable Laser module, as given in Table 10.
- 7 Press the key beside the laser output to switch on the laser.
- 8 Press *Disp*->*Ref* on the 81626B.
- **9** Change the power setting of your Tunable Laser module to the next value listed in the test record and record the power displayed by the 81626B again.
- **10** Record the (rel;ative) power displayed by the 81626B as the "Measured Relative Power from start".
- **11** Calculate the "Power Linearity at current setting" as the sum of "Measured Relative Power from start" and "Power Reduction from start".
- 12 Repeat item 9 to item 11 for all power levels listed in the test record.

- **13** Note the maximum and minimum values of the calculated Power Linearity values for the various settings and record these in the test record.
- **14** Subtract the minimum values from the maximum values of the Power Linearity for the various settings. Record these as the **Total Power Linearity**.

#### Example (Agilent 81689B)

#### **Power Linearity**

	Power Setting from start	Measured Relative Power from start		Power reduction from start		Power Linearity at current setting
Start = REF	+ 10.00 dBm	0.00 dB	+	0.00 dB	=	0.00 dB
	+ 9.00 dBm	- 1.02 dB	+	1.00 dB	=	- 0.02 dB
	+ 8.00 dBm	- 1.92 dB	+	2.00 dB	=	+ 0.08 dB
	+ 7.00 dBm	- 3.02 dB	+	3.00 dB	=	- 0.02 dB
	+ 6.00 dBm	- 3.95 dB	+	4.00 dB	=	+ 0.05 dB
	+ 5.00 dBm	- 5.07 dB	+	5.00 dB	=	- 0.07 dB
	+ 4.00 dBm	- 5.96 dB	+	6.00 dB	=	+ 0.04 dB
	+ 3.00 dBm	- 7.05 dB	+	7.00 dB	=	- 0.05 dB
	+ 2.00 dBm	- 8.01 dB	+	8.00 dB	=	- 0.01 dB
	+ 1.00 dBm	- 8.98 dB	+	8.00 dB	=	+ 0.02 dB
	0.00 dBm	- 9.95 dB	+	9.00 dB	=	- 0.05 dB

Maximum Power Linearity at current setting	+ 0.08 dB
Minimum Power Linearity at current setting	- 0.07 dB
Total Power Linearity = (Max Power Linearity - Min Power Linearity)	0.15 dBpp

### **Power Flatness over Wavelength**

#### **Power Flatness over Wavelength**

- 1 Set up the equipment as shown in Figure 12
- **2** Move to the Tunable Laser channel of the Agilent 8164A/B Lightwave Measurement System and press [Menu].
- **3** Set the menu parameters to the values shown in Table 5.
- **4** Set the wavelength and power for each Tunable Laser module to the values given in Table 11.

## Table 11 Wavelength and Power Settings for Power Flatness over Wavelength at maximum output power

Module	Wavelength $[\lambda]$	Power [P]
Agilent 81689A	1525.000 nm	+6.000 dBm
Agilent 81689B	1525.000 nm	+10.000 dBm
Agilent 81649A	1570.000 nm	+6.000 dBm

- **5** Set the power meter channel of the 81626B to the following settings:
  - **a** While the laser is switched off, Zero the power meter; from [Menu], select [Zero].
  - **b** Select Automatic ranging. This is the default setting.
  - c Set the Averaging Time to 500 ms.
  - d Set  $\lambda$ , the wavelength, to the same as your Tunable Laser module, as given in Table 11.
  - e Select dB as the power units.
- **6** Press the key beside the laser output to switch on the laser.
- 7 Select the channel for the 81626B. Press the *DISP->REF* hardkey.
- 8 Increase the wavelength of the Tunable Laser module and of the Power Meter to the next value listed in the test record.
- **9** Measure the change in output power. Note this value (in dB) in the test record.
- **10** Repeat steps 7 and 8 for the wavelength settings given in the test record.
- **11** From the measurement results calculate the difference between the maximum and minimum deviation from REF and note the result as the Flatness.

12 Set wavelength and power as given in Table 12..

 
 Table 12
 Wavelength and Power Settings for Power Flatness over Wavelength at minimum output power

Module	Wavelength $[\lambda]$	Power [P]	
Agilent 81689A	1525.000 nm	- 3.000 dBm	
Agilent 81689B	1525.000 nm	+0.000 dBm	
Agilent 81649A	1570.000 nm	- 3.000 dBm	

13 Set the power meter channel of the 81626B to the following settings:

- a Select Automatic ranging. This is the default setting.
- **b** Set the Averaging Time to 500 ms.
- c Set  $\lambda$ , the wavelength, to the same as your Tunable Laser module, as given in Table 12.
- d Select dB as the power units.
- 14 Make sure the laser is switched on.

**15** Select the channel for the 81626B. Press the *DISP->REF* hardkey.

- **16** Increase the wavelength of the Tunable Laser module and of the Power Meter to the next value listed in the test record.
- **17** Measure the change in output power. Note this value (in dB) in the test record.
- **18** Repeat steps 15 and 16 for the wavelength settings given in the test record.
- **19** From the measurement results calculate the difference between the maximum and minimum deviation from REF and note the result as the Flatness.

### **Power Stability**

Follow the steps below to measure the power stability:

- **1** Set up the equipment as shown in Figure 12.
- **2** Move to the Tunable Laser channel of the Agilent 8164A/B Lightwave Measurement System and press [Menu].
- **3** Set the menu parameters to the values shown in Table 5.
- **4** Set the wavelength and power for each Tunable Laser module to the values given in Table 13.

#### Table 13 Wavelength and Power Settings for Power Stability Tests

Module	Wavelength $[\lambda]$	Power [P]
Agilent 81689A	1540.000 nm	– 3.00 dBm
Agilent 81689B	1540.000 nm	– 0.00 dBm
Agilent 81649A	1570.000 nm	– 3.00 dBm

**5** Make sure the optical output is switched off.

- 6 Zero the power meter. From [Menu], select [Zero].
- 7 Press the key beside the laser output to switch on the laser.
- 8 Select the logging application. Press [Appl], select [Logging]
- **9** Within the logging application, set the power meter:
- Set  $\lambda$ , the wavelength, to the same as your Tunable Laser module, as given in Table 13.
- Set Range to 0 dB
- Set Ref mode to Value
- Set Samples to 4000
- Set the Average Time to 200 ms
- Set Range mode to common
- Set Power Unit to dB
- Set Ref to the value given in Table 13.
- **10** Start the Logging Application by pressing [Measure] A measurement progress indicator is displayed.
- **11** When the measurement is completed, select [Analysis]

**12** From the Statistics window, note:

- the "max" value in the Maximum Deviation field of the test record,
- the "min" value in the Minimum Deviation field of the test record,

- the " $\Delta P$ " value in the Power Stability field of the test record.
- **NOTE** It is sufficient to test Power Stability for approximately 15 minutes, rather than 1 hour, since this ensures that the power control loop works correctly.

## **Optional Tests**

#### Signal-to-Source Spontaneous Emission

See *"Specifications" on page 33* for a definition of Signal-to-Source Spontaneous Emission.

#### Signal-to-Source Spontaneous Emission Tests

**1** Connect the Tunable Laser module to the Optical Spectrum Analyzer as shown in Figure 13.



#### Figure 13 Test Setup for the Source Spontaneous Emission Test - High Power Outputs

- **2** Move to the Tunable Laser channel of the Agilent 8164A/B Lightwave Measurement System and press [Menu].
- **3** Set the menu parameters to the values shown in Table 5
- **4** Make sure that the optical power output is switched off.

**5** Set the wavelenght of your Tunable Laser module to the value given in Table 14.

 Table 14
 Wavelength Settings for Source Spontaneous Emmission Tests

Module	Wavelength $[\lambda]$
Agilent 81689A	1525.000 nm
Agilent 81689B	1525.000 nm
Agilent 81649A	1570.000 nm

- **6** Set the power for each Tunable Laser module to the maximum specified output power given in the Test Record.
- 7 Press the key beside the laser output to switch on the laser.
- 8 Initialize the Optical Specrum Analyzer. Press [Preset] (the green hardkey) and [Auto Meas].
- **9** Set the Optical Spectrum Analyzer:
  - **a** Set Span to 4 nm. Press [Span], enter the value.
  - **b** Set the Resolution Bandwidth to 0.5 nm. Press [Res BW] and enter the value.
  - c Set the Sensitivity to -60 dBm. Press [SENS], and enter the value.
- **10** On the Spectrum Analyser, set the Marker to the highest peak. Press [Peak Search]
- **11** Select a second marker. Press  $[\Delta]$  (delta).
- **12** Use the RPG, the Modify knob, to view and move the second marker to the highest peak of the displayed side modes and note the difference, delta, between the two markers as an absolute number.





13 To reflect for a specified value at 1 nm bandwidth related to the measurement bandwidth of 0.5 nm, reduce the measured absolute value by 3 dB and note the result in the test record.

For example:	
measured value at RES BW = 0.05 $nm \ BW$	- 44.5 dB
absolute of measured value at RES BW = 0.05 $nm \ BW$	44.5 dB
correction to a RES BW = 1 $nm$	44.5 dB - 3 dB = 41.5 dB
Result noted in Test Record	41.5 dB

- 14 Increase the wavelength of the Tunable Laser by 10 nm as listed in the Test Record.
  - Change the Center Wavelength of the Specrum analyser accordingly. Press [Center], then enter the new wavelength.
  - You can fine-tune the actual wavelength to the center of the display by using the Modify knob.
- **15** Repeat steps 10 to 14 for the wavelength range listed in the Test Record.

## **Test Record**

#### Test Record

## **Agilent 81689A Performance Test**

Page 1 of 7

Test Facility:	
	Report No
	Date
	Customer
	Tested By
Model	Agilent 81689A Tunable Laser Module 1550 nm
Serial No.	Ambient temperature°C
Options	Relative humidity %
Firmware Rev.	Line frequency Hz
Special Notes:	

Agilent 81689A Performance Test

		Page 2 of 7	1
Model Agilent 81689A Tunable Laser	Report No	Date	

### Test Equipment Used

Description	Model No.	Trace No.	Cal. Due Date
1. Lightwave Measurement System	8164A/B		n/a
2. Lightwave Multimeter	8163A/B		n/a
3. Optical Head Interface Module Optical Head Interface Module	81618A 81619A		n/a n/a
4. Standard Optical Head Standard Optical Head	81626B		
5. Optical Spectrum Analyzer			
6. Wavelength Meter			
7			
8			
9			
10			
11			
12			
13			
14			

Agilent 81689A Performance Test Model Agilent 81689A Tunable Laser Page 3 of 7 Report No. \_\_\_\_\_ Date\_\_\_\_\_

	Repetition 1		Repetition 2		Repetition 3	
Wavelength Setting	Wavelength Measured	Wavelength Deviation <sup>1</sup>	Wavelength Measured	Wavelength Deviation <sup>1</sup>	Wavelength Measured	Wavelength Deviation <sup>1</sup>
1525.000 nm	nm	nm	nm	nm	nm	nm
1535.000 nm	nm	nm	nm	nm	nm	nm
1545.000 nm	nm	nm	nm	nm	nm	nm
1555.000 nm	nm	nm	nm	nm	nm	nm
1565.000 nm	nm	nm	nm	nm	nm	nm
1575.000 nm	nm	nm	nm	nm	nm	nm
Within full Tuning Range 1525 to 1575 nm						
Maximum Deviat	ion	nm		nm		nm
Minimum Deviati	on	nm		nm		nm

#### **Relative Wavelength Accuracy**

	Repetition 4		Repetition 5			
Wavelength Setting	Wavelength Measured	Wavelength Deviation <sup>1</sup>	Wavelength Measured	Wavelength Deviation <sup>1</sup>		
1525.000 nm	nm	nm	nm	nm		
1535.000 nm	nm	nm	nm	nm		
1545.000 nm	nm	nm	nm	nm		
1555.000 nm	nm	nm	nm	nm		
1565.000 nm	nm	nm	nm	nm		
1575.000 nm	nm	nm	nm	nm		
Within full Tuning Range 1525 to 1575 nm						
Maximum Deviation				nm		
Minimum Deviation nm n						

<sup>1</sup> Wavelength Deviation = Wavelength Measured - Wavelength Setting

<b>Relative Wavelength Accuracy</b>	Largest Maximum Deviation	nm
Summary of All Repetitions	Smallest Minimum Deviation	nm
Relative Wavelength Accuracy Result	esult (= Largest Maximum Deviation – Smallest Minimur Relative Wavelength Accuracynm	
	Specification:	0.6 nm
	Measurement Uncertainty:	$\pm 0.2$ pm

Agilent 81689A Performance Tes	st		Page 4 of 7
Model Agilent 81689A Tunable	Laser	Report No	Date
Absolute Wavelength Accuracy Result	Largest Value of Deviation Deviation or Smallest Mini	(= largest value of eith mum Deviation)	ner Largest Maximum
	Absolute Wavelength Accu	racynm	
	Test Limit:	1.0 nm	
	Specification:	0.6 nm typical	
	Measurement Uncertainty:	$\pm 0.6 \text{ pm}$	

### Wavelength Repeatability

Repeatability of 1525.000 nm (= reference)	Measurement Result		Repeatability of 1550.000 nm (= reference)	Measurement Result	
Initial Setting	REF =	nm	Initial Setting	REF = nm	
from 1535.000 nm to REF		nm	from 1525.000 nm to REF	nm	
from 1540.000 nm to REF		nm	from 1535.000 nm to REF	nm	
from 1550.000 nm to REF		nm	from 1540.000 nm to REF	nm	
from 1560.000 nm to REF		nm	from 1560.000 nm to REF	nm	
from 1575.000 nm to REF		nm	from 1575.000 nm to REF	nm	
largest measured wavelength		nm	largest measured wavelength	nm	
smallest measured wavelength		nm	smallest measured wavelength	nm	
Wavelength Repeatability		nm	Wavelength Repeatability	nm	
= largest measured wavelength - smallest measured wavelength		jth	= largest measured wavelength - s	mallest measured wavelength	
Specification	0.10 nm		Specification	0.10 nm	

Repeatability of 1575.000 nm (= reference)	Measurement Result	
Initial Setting	REF = nm	
from 1525.000 nm to REF	nm	
from 1535.000 nm to REF	nm	
from 1540.000 nm to REF	nm	
from 1550.000 nm to REF	nm	
from 1560.000 nm to REF	nm	
largest measured wavelength	nm	
smallest measured wavelength	nm	
Wavelength Repeatability	nm	
= largest measured wavelength - smallest measured wavelength		
Specification	0.10 nm	

Measurement Uncertainty:  $\pm 0.1$  pm

Page 5 of 7

Agilent 81689A Performance Test

Model Agilent 81689A Tunable Laser

Report No. \_\_\_\_\_ Date\_\_\_\_\_

#### **Maximum Power Test**

Wavelength Setting	Power Measured	Minimum Specification
1525.000 nm	dBm	+ 6.00 dBm
1535.000 nm	dBm	+ 6.00 dBm
1540.000 nm	dBm	+ 6.00 dBm
1550.000 nm	dBm	+ 6.00 dBm
1560.000 nm	dBm	+ 6.00 dBm
1570.000 nm	dBm	+ 6.00 dBm
1575.000 nm	dBm	+ 6.00 dBm

Measurement Uncertainty:  $\pm 0.10 \text{ dB}$ 

#### **Power Linearity**

	Power Setting from start	Measured Relative Power from start		Power reduction from start		Power Linearity at current setting
Start = REF	+ 6.00 dBm	0.00 dB	+	0.00 dB	Ш	0.00 dB
	+ 5.00 dBm	dB	+	1.00 dB	=	dB
	+ 4.00 dBm	dB	+	2.00 dB	=	dB
	+ 3.00 dBm	dB	+	3.00 dB	=	dB
	+ 2.00 dBm	dB	+	4.00 dB	=	dB
	+ 1.00 dBm	dB	+	5.00 dB	=	dB
	– 0.0 dBm	dB	+	6.00 dB	=	dB
	– 1.0 dBm	dB	+	7.00 dB	=	dB
	– 2.0 dBm	dB	+	8.00 dB	=	dB
	— 3.0 dBm	dB	+	9.00 dB	=	dB

Maximum Power Linearity at current setting	dB
Minimum Power Linearity at current setting	dB
Total Power Linearity = (Max Power Linearity – Min Power Linearity)	dBpp
Specification	0.2 dBpp
Measurement Uncertainty	$\pm 0.05 \text{ dB}$

Agilent 81689A Performance Test Model Agilent 81689A Tunable Laser Page 6 of 7 Report No. \_\_\_\_\_ Date\_\_\_\_\_

#### **Power Flatness**

	Wavelength	Power Deviation at P = + 6.0 dBm	Power Deviation at P = - 3.0 dBm
Start = REF	1525 nm	0.00 dB	0.00 dB
	1530 nm	dB	dB
	1540 nm	dB	dB
	1550 nm	dB	dB
	1560 nm	dB	dB
	1570 nm	dB	dB
	1575 nm	dB	dB
	Maximum deviation	dB	dB
	Minimum deviation	dB	dB
Flatness =	Maximum – Minimum Deviation	dB	dB
	Specification	0.60 dBpp	0.60 dBpp
	Measurement Uncertainty	$\pm$ 0.10 dB	$\pm$ 0.10 dB

### **Power Stability**

	P = -3.0  dBm
Maximum Deviation	dB
Minimum Deviation	dB
Power Stability <sup>1</sup>	dB
Specification	0.06 dBpp
Measurement Uncertainty	$\pm$ 0.005 dB

<sup>1</sup> Power Stability = Maximum Deviation – Minimum Deviation

Agilent 81689A Performance Test Model Agilent 81689A Tunable Laser

	Page 7 of 7
Report No.	Date

## **Optional Test**

### Signal-to-Source Spontaneous Emission (BW = 1 nm)

Wavelength	Output Power	Results	Minimum Test Limit	Typical
1525 nm	+ 6.00 dBm	dB	30 dB	39 dB
1535 nm	+ 6.00 dBm	dB	30 dB	39 dB
1545 nm	+ 6.00 dBm	dB	30 dB	39 dB
1555 nm	+ 6.00 dBm	dB	30 dB	39 dB
1565 nm	+ 6.00 dBm	dB	30 dB	39 dB
1575 nm	+6.00 dBm	dB	30 dB	39 dB

Measurement Uncertainty:  $\pm 0.20 \text{ dB}$
### Test Record

## Agilent 81689B Performance Test

Page 1 of 7

Test Facility:	
	Report No
	Date
	Customer
	Tested By
Model Ag	gilent 81689B Tunable Laser Module 1550 nm
Serial No.	Ambient temperature°C
Options	Relative humidity%
Firmware Rev	Line frequency Hz
Special Notes:	

Agilent 81689B Performance Test

		Page 2 of 7	7
Model Agilent 81689B Tunable Laser	Report No	Date	

## Test Equipment Used

Description	Model No.	Trace No.	Cal. Due Date
1. Lightwave Measurement System	8164A/B		n/a
2. Lightwave Multimeter	8163A/B		n/a
3. Optical Head Interface Module Optical Head Interface Module	81618A 81619A		n/a n/a
4. Standard Optical Head Standard Optical Head	81626B		
5. Optical Spectrum Analyzer			
6. Wavelength Meter			
7			
8			
9			
10			
11			
12			
13	·		
14			

Agilent 81689B Performance Test Model Agilent 81689B Tunable Laser Page 3 of 7 Report No. \_\_\_\_\_ Date\_\_\_\_\_

	Repetition 1		Repetition 2		Repetition 3	
Wavelength Setting	Wavelength Measured	Wavelength Deviation <sup>1</sup>	Wavelength Measured	Wavelength Deviation <sup>1</sup>	Wavelength Measured	Wavelength Deviation <sup>1</sup>
1525.000 nm	nm	nm	nm	nm	nm	nm
1535.000 nm	nm	nm	nm	nm	nm	nm
1545.000 nm	nm	nm	nm	nm	nm	nm
1555.000 nm	nm	nm	nm	nm	nm	nm
1565.000 nm	nm	nm	nm	nm	nm	nm
1575.000 nm	nm	nm	nm	nm	nm	nm
Within full Tuning Range 1525 to 1575 nm						
Maximum Deviat	ion	nm		nm		nm
Minimum Deviati	on	nm		nm		nm

### **Relative Wavelength Accuracy**

	Repetition 4		Repetition 5			
Wavelength Setting	Wavelength Measured	Wavelength Deviation <sup>1</sup>	Wavelength Measured	Wavelength Deviation <sup>1</sup>		
1525.000 nm	nm	nm	nm	nm		
1535.000 nm	nm	nm	nm	nm		
1545.000 nm	nm	nm	nm	nm		
1555.000 nm	nm	nm	nm	nm		
1565.000 nm	nm	nm	nm	nm		
1575.000 nm	nm	nm	nm	nm		
Within full Tuning Range 1525 to 1575 nm						
Maximum Deviat	laximum Deviation nm		nm			
Minimum Deviati	on	nm		nm		

<sup>1</sup> Wavelength Deviation = Wavelength Measured - Wavelength Setting

<b>Relative Wavelength Accuracy</b>	Largest Maximum Deviation	nm
Summary of All Repetitions	Smallest Minimum Deviation	nm
Relative Wavelength Accuracy Result	t (= Largest Maximum Deviation – Smallest Minimum Devi Relative Wavelength Accuracynm	
	Specification:	0.3 nm
	Measurement Uncertainty:	$\pm 0.2$ pm

Agilent 81689A, 81689B and 81649A Tunable Laser Modules User's Guide, Third Edition

Agilent 81689B Performance Tes	st		Page 4 of 7
Model Agilent 81689B Tunable	Laser	Report No	Date
Absolute Wavelength Accuracy Result	Largest Value of Deviation ( Deviation or Smallest Minir	(= largest value of eit num Deviation)	her Largest Maximum
	Absolute Wavelength Accur	acynm	
	Test Limit:	1.0 nm	
	Specification:	0.6 nm typica	1
	Measurement Uncertainty:	$\pm 0.6  \mathrm{pm}$	

## Wavelength Repeatability

Repeatability of 1525.000 nm (= reference)	Measurement Result			Repeatability of 1550.000 nm (= reference)	Measurement Result
Initial Setting	REF =	nm		Initial Setting	REF = nm
from 1535.000 nm to REF		nm		from 1525.000 nm to REF	nm
from 1540.000 nm to REF		nm		from 1535.000 nm to REF	nm
from 1550.000 nm to REF		nm		from 1540.000 nm to REF	nm
from 1560.000 nm to REF		nm		from 1560.000 nm to REF	nm
from 1575.000 nm to REF		nm		from 1575.000 nm to REF	nm
largest measured wavelength		nm		largest measured wavelength	nm
smallest measured wavelength		nm	:	smallest measured wavelength	nm
Wavelength Repeatability		nm		Wavelength Repeatability	nm
= largest measured wavelength - smallest measured wavelength				= largest measured wavelength - s	mallest measured wavelength
Specification	0.10 nm			Specification	0.10 nm

Repeatability of 1575.000 nm (= reference)	Measurement Result	
Initial Setting	REF = nm	
from 1525.000 nm to REF	nm	
from 1535.000 nm to REF	nm	
from 1540.000 nm to REF	nm	
from 1550.000 nm to REF	nm	
from 1560.000 nm to REF	nm	
largest measured wavelength	nm	
smallest measured wavelength	nm	
Wavelength Repeatability	nm	
= largest measured wavelength - smallest measured wavelength		
Specification	0.10 nm	

Measurement Uncertainty:  $\pm 0.1$  pm

Page 5 of 7

Agilent 81689B Performance Test

Model Agilent 81689B Tunable Laser

Report No. \_\_\_\_\_ Date\_\_\_\_\_

#### **Maximum Power Test**

Wavelength Setting	Power Measured	Minimum Specification
1525.000 nm	dBm	+ 10.00 dBm
1535.000 nm	dBm	+ 10.00 dBm
1540.000 nm	dBm	+ 10.00 dBm
1550.000 nm	dBm	+ 10.00 dBm
1560.000 nm	dBm	+ 10.00 dBm
1570.000 nm	dBm	+ 10.00 dBm
1575.000 nm	dBm	+ 10.00 dBm

Measurement Uncertainty:  $\pm 0.10 \text{ dB}$ 

### **Power Linearity**

	Power Setting from start	Measured Relative Power from start		Power reduction from start		Power Linearity at current setting
Start = REF	+ 10.00 dBm	0.00 dB	+	0.00 dB	=	0.00 dB
	+ 9.00 dBm	dB	+	1.00 dB	=	dB
	+ 8.00 dBm	dB	+	2.00 dB	=	dB
	+ 7.00 dBm	dB	+	3.00 dB	=	dB
	+ 6.00 dBm	dB	+	4.00 dB	=	dB
	+ 5.00 dBm	dB	+	5.00 dB	=	dB
	+ 4.00 dBm	dB	+	6.00 dB	=	dB
	+ 3.00 dBm	dB	+	7.00 dB	=	dB
	+ 2.00 dBm	dB	+	8.00 dB	=	dB
	+ 1.00 dBm	dB	+	9.00 dB	=	dB
	0.00 dBm	dB	+	10.00 dB	=	dB

Maximum Power Linearity at current setting	dB
Minimum Power Linearity at current setting	dB
Total Power Linearity = (Max Power Linearity – Min Power Linearity)	dBpp
Specification	0.2 dBpp
Measurement Uncertainty	$\pm 0.05 \text{ dB}$

Agilent 8168B Performance Test Model Agilent 81689B Tunable Laser Page 6 of 7 Report No. \_\_\_\_\_ Date\_\_\_\_\_

### **Power Flatness**

	Wavelength	Power Deviation at P = + 10.0 dBm	Power Deviation at P = - 3.0 dBm
Start = REF	1525 nm	0.00 dB	0.00 dB
	1530 nm	dB	dB
	1540 nm	dB	dB
	1550 nm	dB	dB
	1560 nm	dB	dB
	1570 nm	dB	dB
	1575 nm	dB	dB
	Maximum deviation	dB	dB
	Minimum deviation	dB	dB
Flatness =	Maximum – Minimum Deviation	dB	dB
	Specification	0.40 dBpp	0.40 dBpp
	Measurement Uncertainty	$\pm$ 0.10 dB	$\pm$ 0.10 dB

## **Power Stability**

	P = 0.0 dBm
Maximum Deviation	dB
Minimum Deviation	dB
Power Stability <sup>1</sup>	dB
Specification	0.03 dBpp
Measurement Uncertainty	$\pm$ 0.005 dB

<sup>1</sup> Power Stability = Maximum Deviation – Minimum Deviation

Agilent 81689B Performance Test Model Agilent 81689B Tunable Laser

	Page 7 of 7
Report No.	Date

## **Optional Test**

## Signal-to-Source Spontaneous Emission (BW = 1 nm)

Wavelength	Output Power	Results	Minimum Test Limit	Typical
1525 nm	+ 10.00 dBm	dB	40 dB	44 dB
1535 nm	+ 10.00 dBm	dB	40 dB	44 dB
1545 nm	+ 10.00 dBm	dB	40 dB	44 dB
1555 nm	+ 10.00 dBm	dB	40 dB	44 dB
1565 nm	+ 10.00 dBm	dB	40 dB	44 dB
1575 nm	+ 10.00 dBm	dB	40 dB	44 dB

Measurement Uncertainty:  $\pm 0.20 \text{ dB}$ 

### Test Record

## **Agilent 81649A Performance Test**

Page 1 of 8

	Keport No	
	Date	
	Customer	
	Tested By	
Model	Agilent 81649A Tunable Laser Module 1595 nm	
Serial No.	Ambient temperature	°C
Options	Relative humidity	%
Firmware Rev.	Line frequency	Hz
Special Notes:		

Agilent 81649A Performance Test

		Page 2 of	8
Model Agilent 81649A Tunable Laser	Report No.	Date	

## Test Equipment Used

Description	Model No.	Trace No.	Cal. Due Date
1. Lightwave Measurement System	8164A/B		n/a
2. Lightwave Multimeter	8163A/B		n/a
3. Optical Head Interface Module Optical Head Interface Module	81618A 81619A		n/a n/a
4. Standard Optical Head Standard Optical Head	81626B		
5. Optical Spectrum Analyzer			
6. Wavelength Meter			
7			
8			
9			
10			
11			
12			
13			
14			

Agilent 81649A Performance Test Model Agilent 81649A Tunable Laser Page 3 of 8 Report No. \_\_\_\_\_ Date\_\_\_\_\_

	Repetition 1		Repetition 2		Repetition 3	
Wavelength Setting	Wavelength Measured	Wavelength Deviation <sup>1</sup>	Wavelength Measured	Wavelength Deviation <sup>1</sup>	Wavelength Measured	Wavelength Deviation <sup>1</sup>
1570.000 nm	nm	nm	nm	nm	nm	nm
1575.000 nm	nm	nm	nm	nm	nm	nm
1580.000 nm	nm	nm	nm	nm	nm	nm
1585.000 nm	nm	nm	nm	nm	nm	nm
1590.000 nm	nm	nm	nm	nm	nm	nm
1595.000 nm	nm	nm	nm	nm	nm	nm
1600.000 nm	nm	nm	nm	nm	nm	nm
1605.000 nm	nm	nm	nm	nm	nm	nm
1610.000 nm	nm	nm	nm	nm	nm	nm
1615.000 nm	nm	nm	nm	nm	nm	nm
1620.000 nm	nm	nm	nm	nm	nm	nm
Within full Tuning Range 1525 to 1620 nm						
Maximum Deviatio	n	nm nm		nm		
Minimum Deviation	n	nm	nm		nm	

### **Relative Wavelength Accuracy**

	Repetition 4		Repetition 5	
Wavelength Setting	Wavelength Measured	Wavelength Deviation <sup>1</sup>	Wavelength Measured	Wavelength Deviation <sup>1</sup>
1570.000 nm	nm	nm	nm	nm
1575.000 nm	nm	nm	nm	nm
1580.000 nm	nm	nm	nm	nm
1585.000 nm	nm	nm	nm	nm
1590.000 nm	nm	nm	nm	nm
1595.000 nm	nm	nm	nm	nm
1600.000 nm	nm	nm	nm	nm
1605.000 nm	nm	nm	nm	nm
1610.000 nm	nm	nm	nm	nm
1615.000 nm	nm	nm	nm	nm
1620.000 nm	nm	nm	nm	nm
Within full Tuning Range 1570 to 1620 nm				
Maximum Deviatio	n	nm	nm	
Minimum Deviation	n	nm	nm	

<sup>1</sup> Wavelength Deviation = Wavelength Measured - Wavelength Setting

st		Page 4 of 8
Laser	Report No.	Date
Largest Maximum Deviation	onnm	
Smallest Minimum Deviati	onnm	
(= Largest Maximum Devia Relative Wavelength Accur	ntion – Smallest Minir racynm	num Deviation)
Specification:	0.3 nm	
Measurement Uncertainty:	$\pm 0.2 \text{ pm}$	
Largest Value of Deviation Deviation or Smallest Mini	(= largest value of eit imum Deviation)	ther Largest Maximum
Absolute Wavelength Accu	racynm	
Test Limit:	1.0 nm	
Specification:	0.6 nm typic	al
Measurement Uncertainty:	± 0.6 pm	
	st Laser Largest Maximum Deviation Smallest Minimum Deviation (= Largest Maximum Deviation (= Largest Maximum Deviation (= Largest Maximum Deviation Specification: Measurement Uncertainty: Largest Value of Deviation Deviation or Smallest Minist Absolute Wavelength Accur Test Limit: Specification: Measurement Uncertainty:	st Laser Report Nonm Largest Maximum Deviationnm Smallest Minimum Deviationnm (= Largest Maximum Deviation - Smallest Minin Relative Wavelength Accuracynm Specification: 0.3 nm Measurement Uncertainty: ± 0.2 pm Largest Value of Deviation (= largest value of eit Deviation or Smallest Minimum Deviation) Absolute Wavelength Accuracynm Test Limit: 1.0 nm Specification: 0.6 nm typic Measurement Uncertainty: ± 0.6 pm

## Wavelength Repeatability

Repeatability of 1570.000 nm (= reference)	Measurement Result	Repeatability of 1595.000 nm (= reference)	Measurement Result
Initial Setting	REF = nm	Initial Setting	REF = nm
from 1580.000 nm to REF	nm	from 1570.000 nm to REF	nm
from 1590.000 nm to REF	nm	from 1580.000 nm to REF	nm
from 1600.000 nm to REF	nm	from 1590.000 nm to REF	nm
from 1610.000 nm to REF	nm	from 1610.000 nm to REF	nm
from 1620.000 nm to REF	nm	from 1620.000 nm to REF	nm
largest measured wavelength	nm	largest measured wavelength	nm
smallest measured wavelength	nm	smallest measured wavelength	nm
Wavelength Repeatability	nm	Wavelength Repeatability	nm
= largest measured wavelength - smallest measured wavelength		= largest measured wavelength - s	smallest measured wavelength
Specification	0.10 nm	Specification	0.10 nm

Measurement Uncertainty:  $\pm 0.1 \text{ pm}$ 

Page 5 of 8

Agilent 81689A Performance Test

Model Agilent 81689A Tunable Laser

Report No. \_\_\_\_\_ Date\_\_\_\_

Repeatability of 1620.000 nm (= reference)	Measurement Result
Initial Setting	REF = nm
from 1570000 nm to REF	nm
from 1580.000 nm to REF	nm
from 1590.000 nm to REF	nm
from 1600.000 nm to REF	nm
from 1610.000 nm to REF	nm
largest measured wavelength	nm
smallest measured wavelength	nm
Wavelength Repeatability	nm
= largest measured wavelength - sr	nallest measured wavelength
Specification	0.10 nm

Measurement Uncertainty:  $\pm 0.1 \text{ pm}$ 

#### **Maximum Power Test**

Wavelength Setting	Power Measured	Minimum Specification
1570.000 nm	dBm	+ 6.00 dBm
1575.000 nm	dBm	+ 6.00 dBm
1580.000 nm	dBm	+ 6.00 dBm
1585.000 nm	dBm	+ 6.00 dBm
1590.000 nm	dBm	+ 6.00 dBm
1595.000 nm	dBm	+ 6.00 dBm
1600.000 nm	dBm	+ 6.00 dBm
1605.000 nm	dBm	+ 6.00 dBm
1610.000 nm	dBm	+ 6.00 dBm
1615.000 nm	dBm	+ 6.00 dBm
1620.000 nm	dBm	+ 6.00 dBm

Measurement Uncertainty:  $\pm \ 0.10 \ dB$ 

Page 6 of 8

Agilent 81649A Performance Test

Model Agilent 81649A Tunable Laser

Report No. \_\_\_\_\_ Date\_\_\_\_\_

## **Power Linearity**

	Power Setting from start	Measured Relative Power from start		Power reduction from start		Power Linearity at current setting
Start = REF	+ 6.00 dBm	0.00 dB	+	0.00 dB	=	0.00 dB
	+ 5.00 dBm	dB	+	1.00 dB	=	dB
	+ 4.00 dBm	dB	+	2.00 dB	=	dB
	+ 3.00 dBm	dB	+	3.00 dB	=	dB
	+ 2.00 dBm	dB	+	4.00 dB	=	dB
	+ 1.00 dBm	dB	+	5.00 dB	=	dB
	– 0.0 dBm	dB	+	6.00 dB	=	dB
	— 1.0 dBm	dB	+	7.00 dB	=	dB
	– 2.0 dBm	dB	+	8.00 dB	=	dB
	– 3.0 dBm	dB	+	9.00 dB	=	dB

Maximum Power Linearity at current setting	dB
Minimum Power Linearity at current setting	dB
Total Power Linearity = (Max Power Linearity – Min Power Linearity)	dBpp
Specification	0.2 dBpp
Measurement Uncertainty	$\pm 0.05 \text{ dB}$

Agilent 81689A Performance Test Model Agilent 81689A Tunable Laser Page 7 of 8 Report No. \_\_\_\_\_ Date\_\_\_\_\_

### **Power Flatness**

	Wavelength	Power Deviation at P = + 6.0 dBm	Power Deviation at P = - 3.0 dBm
Start = REF	1570 nm	0.00 dB	0.00 dB
	1575 nm	dB	dB
	1580 nm	dB	dB
	1585 nm	dB	dB
	1590 nm	dB	dB
	1595 nm	dB	dB
	1600 nm	dB	dB
	1605 nm	dB	dB
	1610 nm	dB	dB
	1615 nm	dB	dB
	1620 nm	dB	dB
	Maximum deviation	dB	dB
	Minimum deviation	dB	dB
Flatness =	Maximum – Minimum Deviation	dB	dB
	Specification	0.40 dBpp	0.40 dBpp
	Measurement Uncertainty	$\pm$ 0.10 dB	$\pm$ 0.10 dB

### **Power Stability**

	P = - 3.0 dBm
Maximum Deviation	dB
Minimum Deviation	dB
Power Stability <sup>1</sup>	dB
Specification	0.03 dBpp
Measurement Uncertainty	$\pm$ 0.005 dB

<sup>1</sup> Power Stability = Maximum Deviation – Minimum Deviation

Agilent 81649A Performance Test Model Agilent 81649A Tunable Laser

	Page 8 of 8
Report No.	Date

## **Optional Test**

## Signal-to-Source Spontaneous Emission (BW = 1 nm)

Wavelength	Output Power	Results	Minimum Test Limit	Typical
1525 nm	+ 6.00 dBm	dB	37 dB	42 dB
1535 nm	+ 6.00 dBm	dB	37 dB	42 dB
1545 nm	+ 6.00 dBm	dB	37 dB	42 dB
1555 nm	+ 6.00 dBm	dB	37 dB	42 dB
1565 nm	+ 6.00 dBm	dB	37 dB	42 dB
1575 nm	+6.00 dBm	dB	37 dB	42 dB

Measurement Uncertainty: ± 0.20 dB

**Cleaning Information** 

The following Cleaning Information contains some general safety precautions, which must be observed during all phases of cleaning. Consult your specific optical device manuals or guides for full information on safety matters.

Please try, whenever possible, to use physically contacting connectors, and dry connections. Clean the connectors, interfaces, and bushings carefully after use.

If you are unsure of the correct cleaning procedure for your optical device, we recommend that you first try cleaning a dummy or test device.

Agilent Technologies assume no liability for the customer's failure to comply with these requirements.

#### **Cleaning Instructions for this Instrument**

This Cleaning Information applies to a number of different types of Optical Equipment.

"How to clean instruments with a physical contact interface" on page 103 is particularly relevant to this module.

## **Safety Precautions**

Please follow the following safety rules:

- · Do not remove instrument covers when operating.
- Ensure that the instrument is switched off throughout the cleaning procedures.
- Use of controls or adjustments or performance of procedures other than those specified may result in hazardous radiation exposure.
- Make sure that you disable all sources when you are cleaning any optical interfaces.
- Under no circumstances look into the end of an optical device attached to optical outputs when the device is operational. The laser radiation is not visible to the human eye, but it can seriously damage your eyesight.
- To prevent electrical shock, disconnect the instrument from the mains before cleaning. Use a dry cloth, or one slightly dampened with water, to clean the external case parts. Do not attempt to clean internally.
- Do not install parts or perform any unauthorized modification to optical devices.
- Refer servicing only to qualified and authorized personnel.

# Why is it important to clean optical devices?

In transmission links optical fiber cores are about 9  $\mu$ m (0.00035") in diameter. Dust and other particles, however, can range from tenths to hundredths of microns in diameter. Their comparative size means that they can cover a part of the end of a fiber core, and as a result will reduce the performance of your system.

Furthermore, the power density may burn dust into the fiber and cause additional damage (for example, 0 dBm optical power in a single mode fiber causes a power density of approximately 16 million  $W/m^2$ ). If this happens, measurements become inaccurate and non-repeatable.

Cleaning is, therefore, an essential yet difficult task. Unfortunately, when comparing most published cleaning recommendations, you will discover that they contain several inconsistencies. In this section, we want to suggest ways to help you clean your various optical devices, and thus significantly improve the accuracy and repeatability of your lightwave measurements.

# What do I need for proper cleaning?

Some Standard Cleaning Equipment is necessary for cleaning your instrument. For certain cleaning procedures, you may also require certain Additional Cleaning Equipment.

### **Standard Cleaning Equipment**

Before you can start your cleaning procedure you need the following standard equipment:

- Dust and shutter caps
- Isopropyl alcohol
- Cotton swabs
- Soft tissues
- Pipe cleaner
- · Compressed air

#### Dust and shutter caps

All of Agilent Technologies' lightwave instruments are delivered with either laser shutter caps or dust caps on the lightwave adapter. Any cables come with covers to protect the cable ends from damage or contamination. We suggest these protective coverings should be kept on the equipment at all times, except when your optical device is in use. Be careful when replacing dust caps after use. Do not press the bottom of the cap onto the fiber too hard, as any dust in the cap can scratch or pollute your fiber surface.

If you need further dust caps, please contact your nearest Agilent Technologies sales office.

#### Isopropyl alcohol

This solvent is usually available from any local pharmaceutical supplier or chemist's shop.

If you use isopropyl alcohol to clean your optical device, do not immediately dry the surface with compressed air (except when you are cleaning very sensitive optical devices). This is because the dust and the dirt is solved and will leave behind filmy deposits after the alcohol is evaporated. You should therefore first remove the alcohol and the dust with a soft tissue, and then use compressed air to blow away any remaining filaments.

If possible avoid using denatured alcohol containing additives. Instead, apply alcohol used for medical purposes.

Never drink this alcohol, as it may seriously damage to your health.

Do not use any other solvents, as some may damage plastic materials and claddings. Acetone, for example, will dissolve the epoxy used with fiber optic connectors. To avoid damage, only use isopropyl alcohol.

#### Cotton swabs

We recommend that you use swabs such as Q-tips or other cotton swabs normally available from local distributors of medical and hygiene products (for example, a supermarket or a chemist's shop). You may be able to obtain various sizes of swab. If this is the case, select the smallest size for your smallest devices.

Ensure that you use natural cotton swabs. Foam swabs will often leave behind filmy deposits after cleaning.

Use care when cleaning, and avoid pressing too hard onto your optical device with the swab. Too much pressure may scratch the surface, and could cause your device to become misaligned. It is advisable to rub gently over the surface using only a small circular movement.

Swabs should be used straight out of the packet, and never used twice. This is because dust and dirt in the atmosphere, or from a first cleaning, may collect on your swab and scratch the surface of your optical device.

#### Soft tissues

These are available from most stores and distributors of medical and hygiene products such as supermarkets or chemists' shops.

We recommend that you do not use normal cotton tissues, but multilayered soft tissues made from non-recycled cellulose. Cellulose tissues are very absorbent and softer. Consequently, they will not scratch the surface of your device over time.

Use care when cleaning, and avoid pressing on your optical device with the tissue. Pressing too hard may lead to scratches on the surface or misalignment of your device. Just rub gently over the surface using a small circular movement.

Use only clean, fresh soft tissues and never apply them twice. Any dust and dirt from the air which collects on your tissue, or which has gathered after initial cleaning, may scratch and pollute your optical device.

#### **Pipe cleaner**

Pipe cleaners can be purchased from tobacconists, and come in various shapes and sizes. The most suitable one to select for cleaning purposes has soft bristles, which will not produces scratches.

There are many different kinds of pipe cleaner available from tobacco nists.

The best way to use a pipe cleaner is to push it in and out of the device opening (for example, when cleaning an interface). While you are cleaning, you should slowly rotate the pipe cleaner.

Only use pipe cleaners on connector interfaces or on feed through adapters. Do not use them on optical head adapters, as the center of a pipe cleaner is hard metal and can damage the bottom of the adapter.

Your pipe cleaner should be new when you use it. If it has collected any dust or dirt, this can scratch or contaminate your device.

The tip and center of the pipe cleaner are made of metal. Avoid accidentally pressing these metal parts against the inside of the device, as this can cause scratches.

#### **Compressed air**

Compressed air can be purchased from any laboratory supplier.

It is essential that your compressed air is free of dust, water and oil. Only use clean, dry air. If not, this can lead to filmy deposits or scratches on the surface of your connector. This will reduce the performance of your transmission system. When spraying compressed air, hold the can upright. If the can is held at a slant, propellant could escape and dirty your optical device. First spray into the air, as the initial stream of compressed air could contain some condensation or propellant. Such condensation leaves behind a filmy deposit.

Please be friendly to your environment and use a CFC-free aerosol.

### Additional Cleaning Equipment

Some Cleaning Procedures need the following equipment, which is not required to clean each instrument:

- Microscope with a magnification range about 50X up to 300X
- Ultrasonic bath
- Warm water and liquid soap
- Premoistened cleaning wipes
- Polymer film
- Infrared Sensor Card

# Microscope with a magnification range about 50X up to 300X

A microscope can be found in most photography stores, or can be obtained through or specialist mail order companies. Special fiberscopes are available from suppliers of splicing equipment.

Ideally, the light source on your microscope should be very flexible. This will allow you to examine your device closely and from different angles.

A microscope helps you to estimate the type and degree of dirt on your device. You can use a microscope to choose an appropriate cleaning method, and then to examine the results. You can also use your microscope to judge whether your optical device (such as a connector) is severely scratched and is, therefore, causing inaccurate measurements.

#### Ultrasonic bath

Ultrasonic baths are also available from photography or laboratory suppliers or specialist mail order companies.

An ultrasonic bath will gently remove fat and other stubborn dirt from your optical devices. This helps increase the life span of the optical devices. Only use isopropyl alcohol in your ultrasonic bath, as other solvents may cause damage.

#### Warm water and liquid soap

Only use water if you are sure that there is no other way of cleaning your optical device without causing corrosion or damage. Do not use hot water, as this may cause mechanical stress, which can damage your optical device.

Ensure that your liquid soap has no abrasive properties or perfume in it. You should also avoid normal washing up liquid, as it can cover your device in an iridescent film after it has been air dried.

Some lenses and mirrors also have a special coating, which may be sensitive to mechanical stress, or to fat and liquids. For this reason we recommend you do not touch them.

If you are not sure how sensitive your device is to cleaning, please contact the manufacturer or your sales distributor.

#### Premoistened cleaning wipes

Use pre-moistened cleaning wipes as described in each individual cleaning procedure. Cleaning wipes may be used in every instance where a moistened soft tissue or cotton swab is applied.

#### **Polymer film**

Polymer film is available from laboratory suppliers or specialist mail order companies.

Using polymer film is a gentle method of cleaning extremely sensitive devices, such as reference reflectors and mirrors.

#### **Infrared Sensor Card**

Infrared sensor cards are available from laboratory suppliers or specialist mail order companies.

With this card you are able to control the shape of laser light emitted. The invisible laser beam is projected onto the sensor card, then becomes visible to the normal eye as a round spot.

Take care never to look into the end of a fiber or any other optical component, when they are in use. This is because the laser can seriously damage your eyes.

# **Preserving Connectors**

	Listed below are some hints on how best to keep your connectors in the best possible condition.
Making Connections	Before you make any connection you must ensure that all cables and connectors are clean. If they are dirty, use the appropriate cleaning procedure.
	When inserting the ferrule of a patchcord into a connector or an adapter, make sure that the fiber end does not touch the outside of the mating connector or adapter. Otherwise you will rub the fiber end against an unsuitable surface, producing scratches and dirt deposits on the surface of your fiber.
Dust Caps and Shutter Caps	Be careful when replacing dust caps after use. Do not press the bottom of the cap onto the fiber as any dust in the cap can scratch or dirty your fiber surface.
	When you have finished cleaning, put the dust cap back on, or close the shutter cap if the equipment is not going to be used immediately.
	Always keep the caps on the equipment when it is not in use.
	All of Agilent Technologies' lightwave instruments and accessories are shipped with either laser shutter caps or dust caps. If you need additional or replacement dust caps, contact your nearest Agilent Technologies Sales/Service Office.
Immersion Oil and Other Index Matching Compounds	Wherever possible, do not use immersion oil or other index matching compounds with your device. They are liable to impair and dirty the surface of the device. In addition, the characteristics of your device can be changed and your measurement results affected.

# **Cleaning Instrument Housings**

Use a dry and very soft cotton tissue to clean the instrument housing and the keypad. Do not open the instruments as there is a danger of electric shock, or electrostatic discharge. Opening the instrument can cause damage to sensitive components, and in addition your warranty will be voided.

# Which Cleaning Procedure should I use ?

# **Light dirt** If you just want to clean away light dirt, observe the following procedure for all devices:

- · Use compressed air to blow away large particles.
- Clean the device with a dry cotton swab.
- Use compressed air to blow away any remaining filament left by the swab.
- Heavy dirtIf the above procedure is not enough to clean your instrument, follow<br/>one of the procedures below. Please consult "Cleaning Instructions<br/>for this Instrument" on page 90 for the procedure relevant for this<br/>instrument.

If you are unsure of how sensitive your device is to cleaning, please contact the manufacturer or your sales distributor

## How to clean connectors

Cleaning connectors is difficult as the core diameter of a single-mode fiber is only about 9  $\mu m$ . This generally means you cannot see streaks or scratches on the surface. To be certain of the condition of the surface of your connector and to check it after cleaning, you need a microscope.

In the case of scratches, or of dust that has been burnt onto the surface of the connector, you may have no option but to polish the connector. This depends on the degree of dirtiness, or the depth of the scratches. This is a difficult procedure and should only be performed by a skilled person, and as a last resort as it wears out your connector.

#### WARNING

Never look into the end of an optical cable that is connected to an active source.

	To assess the projection of the emitted light beam you can use an infrared sensor card. Hold the card approximately 5 cm from the output of the connector. The invisible emitted light is projected onto the card and becomes visible as a small circular spot.
Preferred Procedure	Use the following procedure on most occasions.
	<b>1</b> Clean the connector by rubbing a new, dry cotton swab over the surface using a small circular movement.
	<b>2</b> Blow away any remaining lint with compressed air.
Procedure for Stubborn Dirt	Use this procedure when there is greasy dirt on the connector:
	<b>1</b> Moisten a new cotton swab with isopropyl alcohol.
	<b>2</b> Clean the connector by rubbing the cotton swab over the surface using a small circular movement.
	<b>3</b> Take a new, dry soft tissue and remove the alcohol, dissolved sediment and dust, by rubbing gently over the surface using a small circular movement.
	<b>4</b> Blow away any remaining lint with compressed air.
An Alternative Procedure	A better, more gentle, but more expensive cleaning procedure is to use an ultrasonic bath with isopropyl alcohol.
	<b>1</b> Hold the tip of the connector in the bath for at least three minutes.
	<b>2</b> Take a new, dry soft tissue and remove the alcohol, dissolved sediment and dust, by rubbing gently over the surface using a small circular movement.
	<b>3</b> Blow away any remaining lint with compressed air.

# How to clean connector adapters

#### CAUTION

Some adapters have an anti-reflection coating on the back to reduce back reflection. This coating is extremely sensitive to solvents and mechanical abrasion. Extra care is needed when cleaning these adapters.

<b>Preferred Procedure</b>	Use the following procedure on most occasions.
	<b>1</b> Clean the adapter by rubbing a new, dry cotton swab over the surface using a small circular movement.
	<b>2</b> Blow away any remaining lint with compressed air.
Procedure for Stubborn Dirt	Use this procedure when there is greasy dirt on the adapter:
	<b>1</b> Moisten a new cotton swab with isopropyl alcohol.
	<b>2</b> Clean the adapter by rubbing the cotton swab over the surface using a small circular movement.
	<b>3</b> Take a new, dry soft tissue and remove the alcohol, dissolved sediment and dust, by rubbing gently over the surface using a small circular movement.
	<b>4</b> Blow away any remaining lint with compressed air.

# How to clean connector interfaces

CAUTION	Be careful when using pipe cleaners, as the core and the bristles of the pipe cleaner are hard and can damage the interface.
	Do not use pipe cleaners on optical head adapters, as the hard core of normal pipe cleaners can damage the bottom of an adapter.
Preferred Procedure	Use the following procedure on most occasions.
	<b>1</b> Clean the interface by pushing and pulling a new, dry pipe cleaner into the opening. Rotate the pipe cleaner slowly as you do this.
	<b>2</b> Then clean the interface by rubbing a new, dry cotton swab over the surface using a small circular movement.
	<b>3</b> Blow away any remaining lint with compressed air.
Procedure for Stubborn Dirt	Use this procedure when there is greasy dirt on the interface:
	<b>1</b> Moisten a new pipe cleaner with isopropyl alcohol.
	<b>2</b> Clean the interface by pushing and pulling the pipe cleaner into the opening. Rotate the pipe cleaner slowly as you do this.
	Agilent 81689A, 81689B and 81649A Tunable Laser Modules User's Guide, Third Edition

- **3** Moisten a new cotton swab with isopropyl alcohol.
- **4** Clean the interface by rubbing the cotton swab over the surface using a small circular movement.
- **5** Using a new, dry pipe cleaner, and a new, dry cotton swab remove the alcohol, any dissolved sediment and dust.
- **6** Blow away any remaining lint with compressed air.

# How to clean bare fiber adapters

	Bare fiber adapters are difficult to clean. Protect from dust unless they are in use.
CAUTION	Never use any kind of solvent when cleaning a bare fiber adapter as solvents can:
	• Damage the foam inside some adapters.
	• Deposit dissolved dirt in the groove, which can then dirty the surface of an inserted fiber.
Preferred Procedure	Use the following procedure on most occasions.
	<b>1</b> Blow away any dust or dirt with compressed air.
Procedure for Stubborn Dirt	Use this procedure when there is greasy dirt on the adapter:
	<b>1</b> Clean the adapter by pushing and pulling a new, dry pipe cleaner into the opening. Rotate the pipe cleaner slowly as you do this.
CAUTION	Be careful when using pipe cleaners, as the core and the bristles of the pipe cleaner are hard and can damage the adapter.
	<b>2</b> Clean the adapter by rubbing a new, dry cotton swab over the surface using a small circular movement.
	<b>3</b> Blow away any remaining lint with compressed air.

## How to clean lenses

	Some lenses have special coatings that are sensitive to solvents, grease, liquid and mechanical abrasion. Take extra care when cleaning lenses with these coatings.
	Lens assemblies consisting of several lenses are not normally sealed. Therefore, use as little alcohol as possible, as it can get between the lenses and in doing so can change the properties of projection.
Preferred Procedure	Use the following procedure on most occasions.
	1 Clean the lens by rubbing a new, dry cotton swab over the surface using a small circular movement.
	<b>2</b> Blow away any remaining lint with compressed air.
Procedure for Stubborn Dirt	Use this procedure when there is greasy dirt on the lens:
	<b>1</b> Moisten a new cotton swab with isopropyl alcohol.
	<b>2</b> Clean the lens by rubbing the cotton swab over the surface using a small circular movement.
	<b>3</b> Using a new, dry cotton swab remove the alcohol, any dissolved sediment and dust.
	<b>4</b> Blow away any remaining lint with compressed air.

# How to clean instruments with a fixed connector interface

You should only clean instruments with a fixed connector interface when it is absolutely necessary. This is because it is difficult to remove any used alcohol or filaments from the input of the optical block.

It is important, therefore, to keep dust caps on the equipment at all times, except when your optical device is in use.

If you do discover filaments or particles, the only way to clean a fixed connector interface and the input of the optical block is to use compressed air. If there are fluids or fat in the connector, please refer the instrument to the skilled personnel of Agilent's service team.

CAUTION

Only use clean, dry compressed air. Make sure that the air is free of dust, water, and oil. If the air that you use is not clean and dry, this can lead to filmy deposits or scratches on the surface of your connector interface. This will degrade the performance of your transmission system.

Never try to open the instrument and clean the optical block by yourself, because it is easy to scratch optical components, and cause them to become misaligned.

# How to clean instruments with an optical glass plate

Some instruments, for example, the optical heads from Agilent Technologies have an optical glass plate to protect the sensor. Clean this glass plate in the same way as optical lenses (see *"How to clean lenses" on page 102*).

# How to clean instruments with a physical contact interface

Remove any connector interfaces from the optical output of the instrument before you begin the cleaning procedure.

Cleaning interfaces is difficult as the core diameter of a single-mode fiber is only about 9  $\mu$ m. This generally means you cannot see streaks or scratches on the surface. To be certain of the degree of pollution on the surface of your interface and to check whether it has been removed after cleaning, you need a microscope.

WARNING	Never look into an optical output, because this can seriously damage your eyesight.
	To assess the projection of the emitted light beam you can use an infrared sensor card. Hold the card approximately 5 cm from the interface. The invisible emitted light is projected onto the card and becomes visible as a small circular spot.
Preferred Procedure	Use the following procedure on most occasions.
	<b>1</b> Clean the interface by rubbing a new, dry cotton swab over the surface using a small circular movement.
	<b>2</b> Blow away any remaining lint with compressed air.
Procedure for Stubborn Dirt	Use this procedure when there is greasy dirt on the interface:
	<b>1</b> Moisten a new cotton swab with isopropyl alcohol.
	<b>2</b> Clean the interface by rubbing the cotton swab over the surface using a small circular movement.
	<b>3</b> Take a new, dry soft tissue and remove the alcohol, dissolved sediment and dust, by rubbing gently over the surface using a small circular movement.
	<b>4</b> Blow away any remaining lint with compressed air.

# How to clean instruments with a recessed lens interface

#### WARNING

For instruments with a deeply recessed lens interface (for example the Agilent 81633A and 81634A Power Sensors) do NOT follow this procedure. Alcohol and compressed air could damage your lens even further.

Keep your dust and shutter caps on when your instrument is not in use. This should prevent it from getting too dirty. If you must clean such instruments, please refer the instrument to the skilled personnel of Agilent's service team.

<b>Preferred Procedure</b>	Use the following procedure on most occasions.
	<ol> <li>Blow away any dust or dirt with compressed air.</li> <li>If this is not sufficient, then</li> </ol>
	<b>2</b> Clean the interface by rubbing a new, dry cotton swab over the surface using a small circular movement.
	<b>3</b> Blow away any remaining lint with compressed air.
Procedure for Stubborn Dirt	Use this procedure when there is greasy dirt on the interface, and using the preferred procedure is not sufficient. Using isopropyl alcohol should be your last choice for recessed lens interfaces because of the difficulty of cleaning out any dirt that is washed to the edge of the interface:
	<b>1</b> Moisten a new cotton swab with isopropyl alcohol.
	<b>2</b> Clean the interface by rubbing the cotton swab over the surface using a small circular movement.
	<b>3</b> Take a new, dry soft tissue and remove the alcohol, dissolved sediment and dust, by rubbing gently over the surface using a small circular movement.
	<b>4</b> Blow away any remaining lint with compressed air.

## How to clean optical devices which are sensitive to mechanical stress and pressure

 Some optical devices, such as the Agilent 81000BR Reference Reflector, which has a gold plated surface, are very sensitive to mechanical stress or pressure. Do not use cotton swabs, soft tissues or other mechanical cleaning tools, as these can scratch or destroy the surface.
 Preferred Procedure
 Use the following procedure on most occasions.
 1 Blow away any dust or dirt with compressed air.

Procedure for Stubborn DirtTo clean devices that are extremely sensitive to mechanical stress or<br/>pressure you can also use an optical clean polymer film. This

	procedure is time-consuming, but you avoid scratching or destroying the surface.
	<b>1</b> Put the film on the surface and wait at least 30 minutes to make sure that the film has had enough time to dry.
	<b>2</b> Remove the film and any dirt with special adhesive tapes.
Alternative Procedure	For these types of optical devices you can often use an ultrasonic bath with isopropyl alcohol. Only use the ultrasonic bath if you are sure that it won't cause any damage any part of the device.
	<b>1</b> Put the device into the bath for at least three minutes.
	<b>2</b> Blow away any remaining liquid with compressed air.
	If there are any streaks or drying stains on the surface, repeat the cleaning procedure.

# How to clean metal filters or attenuator gratings

	This kind of device is extremely fragile. A misalignment of the grating leads to inaccurate measurements. Never touch the surface of the metal filter or attenuator grating. Be very careful when using or cleaning these devices. Do not use cotton swabs or soft tissues, as there is the danger that you cannot remove the lint and that the device will be destroyed by becoming mechanically distorted.
Preferred Procedure	Use the following procedure on most occasions.
	<b>1</b> Use compressed air at a distance and with low pressure to remove any dust or lint.
Procedure for Stubborn Dirt	Do not use an ultrasonic bath as this can damage your device.
	Use this procedure when there is greasy dirt on the device:
	<b>1</b> Put the optical device into a bath of isopropyl alcohol, and wait at least 10 minutes.
	<b>2</b> Remove the fluid using compressed air at some distance and with low pressure. If there are any streaks or drying stains on the surface, repeat the whole cleaning procedure.

# **Additional Cleaning Information**

The following cleaning procedures may be used with other optical equipment:

- · How to clean bare fiber ends
- · How to clean large area lenses and mirrors

### How to clean bare fiber ends

Bare fiber ends are often used for splices or, together with other optical components, to create a parallel beam. The end of a fiber can often be scratched. You make a new cleave. To do this:

- **1** Strip off the cladding.
- 2 Take a new soft tissue and moisten it with isopropyl alcohol.
- **3** Carefully clean the bare fiber with this tissue.
- **4** Make your cleave and immediately insert the fiber into your bare fiber adapter in order to protect the surface from dirt.

### How to clean large area lenses and mirrors

Some mirrors, as those from a monochromator, are very soft and sensitive. Therefore, never touch them and do not use cleaning tools such as compressed air or polymer film.

Some lenses have special coatings that are sensitive to solvents, grease, liquid and mechanical abrasion. Take extra care when cleaning lenses with these coatings.

Lens assemblies consisting of several lenses are not normally sealed. Therefore, use as little liquid as possible, as it can get between the lenses and in doing so can change the properties of projection.

Preferred Procedure	Use the following procedure on most occasions.
	1 Blow away any dust or dirt with compressed air.
Procedure for Stubborn Dirt	Use this procedure when there is greasy dirt on the lens:
CAUTION	Only use water if you are sure that there is no other way of cleaning your optical device without causing corrosion or damage.

		Do not use hot water, as this may cause mechanical stress, which can damage your optical device.
		Ensure that your liquid soap has no abrasive properties or perfume in it. You should also avoid normal washing up liquid, as it can cover your device in an iridescent film after it has been air dried.
		Some lenses and mirrors also have a special coating, which may be sensitive to mechanical stress, or to fat and liquids. For this reason we recommend you do not touch them.
		If you are not sure how sensitive your device is to cleaning, please contact the manufacturer or your sales distributor.
		<b>1</b> Moisten the lens or the mirror with water.
		<b>2</b> Put a little liquid soap on the surface and gently spread the liquid over the whole area.
		<b>3</b> Wash off the emulsion with water, being careful to remove it all, as any remaining streaks can impair measurement accuracy.
		<b>4</b> Take a new, dry soft tissue and remove the water, by rubbing gently over the surface using a small circular movement.
		<b>5</b> Blow away remaining lint with compressed air.
	Alternative Procedure A	To clean lenses that are extremely sensitive to mechanical stress or pressure you can also use an optical clean polymer film. This procedure is time-consuming, but you avoid scratching or destroying the surface.
		<b>1</b> Put the film on the surface and wait at least 30 minutes to make sure that the film has had enough time to dry.
		<b>2</b> Remove the film and any dirt with special adhesive tapes.
	Alternative Procedure B	If your lens is sensitive to water then:
		<b>1</b> Moisten the lens or the mirror with isopropyl alcohol.
		<b>2</b> Take a new, dry soft tissue and remove the alcohol, dissolved sediment and dust, by rubbing gently over the surface using a small circular movement.
		<b>3</b> Blow away remaining lint with compressed air.
# **Other Cleaning Hints**

	Selecting the correct cleaning method is an important element in maintaining your equipment and saving you time and money. This Appendix highlights the main cleaning methods, but cannot address every individual circumstance.
	This section contain some additional hints which we hope will help you further. For further information, please contact your local Agilent Technologies representative.
Making the connection	Before you make any connection you must ensure that all lightwave cables and connectors are clean. If not, then use the appropriate cleaning methods.
	When you insert the ferrule of a patchcord into a connector or an adapter, ensure that the fiber end does not touch the outside of the mating connector or adapter. Otherwise, the fiber end will rub up against something which could scratch it and leave deposits.
Lens cleaning papers	Some special lens cleaning papers are not suitable for cleaning optical devices like connectors, interfaces, lenses, mirrors and so on. To be absolutely certain that a cleaning paper is applicable, please ask the salesperson or the manufacturer.
Immersion oil and other index matching compounds	Do not use immersion oil or other index matching compounds with optical sensors equipped with recessed lenses. They are liable to dirty the detector and impair its performance. They may also alter the property of depiction of your optical device, thus rendering your measurements inaccurate.
Cleaning the housing and the mainframe	When cleaning either the mainframe or the housing of your instrument, only use a dry and very soft cotton tissue on the surfaces and the numeric pad.
	Never open the instruments as they can be damaged. Opening the instruments puts you in danger of receiving an electrical shock from your device, and renders your warranty void.

## Index

#### $\mathbf{C}$

Connectors angled contact 22, 31 straight contact 22, 30 Conventions 8

#### D

Definition of Terms 35 Absolute Wavelength Accuracy 35 Linewidth 35 Minimum Output Power 35 Modulation Depth 36 Modulation Frequency Range 36 Output Isolation 36 Output Power 36 Peak Power 36 Polarization Extinction Ratio 36 Power Flatness Versus Wavelength 37 Power Linearity 37 Power Repeatability 37 Power Stability 38 Relative Intensity Noise 38 Relative Wavelength Accurac 38 Return Loss 39 Sidemode Suppression Ratio 39 Signal-to-Source Spontaneous Emission Ratio 39 Wavelength Range 39 Wavelength Repeatability 40 Wavelength Resolution 40 Wavelength Stability 40

### F

```
Front Panel
Agilent 81649A 20
Agilent 81689A 19
Agilent 81689B 20
Controls and Indicators 20
G
Getting Started 17
I
Inspection 3
L
Line Power 4
O
Optical Output 22
Optional features 27
P
```

Performance Tests 46

Agilent 81649A 81 Agilent 81689A 65 Agilent 81689B 73 Instructions 48 Polarization Maintaining Fiber 22 S

Safety symbols 3 Signal Input 23 Signal Output 23 Specifications 41 T Test Records 63 U Use Models 21

User's Guides 28

www.agilent.com

 ${\ensuremath{\mathbb C}}$  Agilent Technologies GmbH 2001 - 2002

Printed in Germany February 20, 2002



81689-90A13

